



ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE



Fine Furniture for every stage of life

115480LTO(B1)

Dining Table Base

ITEM: 115480LTO(B1)

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!


1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION

A	TOP SUPPORT FRAME		1PC
B	CURVED LEG		5PCS
C	BOTTOM BASE		1PC


HARDWARE IDENTIFICATION

1	BOLT (Ø5/16" x 25mm - RBW)		20PCS
2	LOCK WASHER (Ø5/16" x 2mm - RBW)		20PCS
3	FLAT WASHER (Ø5/16" x 2mm - RBW)		20PCS
4	ALLEN WRENCH (4mm x 57mm - RBW)		1PC
5	GLASS GASKET (Ø20mm x 3mm)		4PCS


ITEM: 115480LTO(B1)

ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2




ITEM: 115480LTO(B1)

ASSEMBLY INSTRUCTIONS




STEP 3




STEP 4

COMPLETE



ITEM: **115480LTO(B1)**



Note: Dimension tolerance $\pm 5\%$