



Fine Furniture for every stage of life

224403 Dresser

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



DOL T

ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A	DRESSER	1PC
В	CENTER SUPPORT LEG WITH LEVELER	1PC
С	LEG	4PCS

HARDWARE IDENTIFICATION


1	(M6 x 15MM - RBW)	8PCS
2	FLAT WASHER (1/4" x 19 Ø - RBW)	8PCS
3	ALLEN WRENCH (M4 x 65MM - BLK)	1PC

NOTE:


ASSEMBLY INSTRUCTIONS



STEP 1



STEP 2 COMPLETE







ANTI-TIPPING INSTALLMENT INSTRUCTIONS FURNITURE TIPPING RESTRAINT

WARNING

Injury may result from tipping furniture.


This restraint may protect against tipping furniture.

Do not allow children to climb on furniture.

This restraint is not a substitute for proper adult supervision.

Failure to detach this restraint before moving the furniture may result in injury and damage.

- 1. Attach one of the mounting brackets securely to the back edge of the furniture. Use the short screw.
- 2. Determine where the furniture is to be placed and mark location on the wall for the mounting bracket screw hole approximately 2" below the bracket mounted to the edge of the furniture.
- 3. Drill a 3/16" hole in the wall. Press the plastic wall plug into the hole and gently tap until the flange on the wall plug is against the wall surface.
- 4. Position the bracket over the wall plug and use the long screw to securely attach the bracket to the wall.
- 5. Place the furniture so the bracket on the back edge is in line with the bracket on the wall.
- 6. Lace an end of the cable tie down through each bracket. Bring both ends together and slide the beaded end of the cable tie through the keyhole shaped slot on the other end until snug. Pull down on the beaded end until it snap locks into the keyhole slot.
- 7. To double lock return the beaded end back through the keyhole as shown.
- 8. Check to make sure the cable tie is securely laced and locked to the brackets.










Inner Size of Drawer: 24.50"W X 12.25"D X 5.00"H X 0.25"T







Fine Furniture for every stage of life

224403 Dresser

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



DOL T

ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A	DRESSER	1PC
В	CENTER SUPPORT LEG WITH LEVELER	1PC
С	LEG	4PCS

HARDWARE IDENTIFICATION


1	(M6 x 15MM - RBW)	8PCS
2	FLAT WASHER (1/4" x 19 Ø - RBW)	8PCS
3	ALLEN WRENCH (M4 x 65MM - BLK)	1PC

NOTE:


ASSEMBLY INSTRUCTIONS



STEP 1



STEP 2 COMPLETE







ANTI-TIPPING INSTALLMENT INSTRUCTIONS FURNITURE TIPPING RESTRAINT

WARNING

Injury may result from tipping furniture.


This restraint may protect against tipping furniture.

Do not allow children to climb on furniture.

This restraint is not a substitute for proper adult supervision.

Failure to detach this restraint before moving the furniture may result in injury and damage.

- 1. Attach one of the mounting brackets securely to the back edge of the furniture. Use the short screw.
- 2. Determine where the furniture is to be placed and mark location on the wall for the mounting bracket screw hole approximately 2" below the bracket mounted to the edge of the furniture.
- 3. Drill a 3/16" hole in the wall. Press the plastic wall plug into the hole and gently tap until the flange on the wall plug is against the wall surface.
- 4. Position the bracket over the wall plug and use the long screw to securely attach the bracket to the wall.
- 5. Place the furniture so the bracket on the back edge is in line with the bracket on the wall.
- 6. Lace an end of the cable tie down through each bracket. Bring both ends together and slide the beaded end of the cable tie through the keyhole shaped slot on the other end until snug. Pull down on the beaded end until it snap locks into the keyhole slot.
- 7. To double lock return the beaded end back through the keyhole as shown.
- 8. Check to make sure the cable tie is securely laced and locked to the brackets.










Inner Size of Drawer: 24.50"W X 12.25"D X 5.00"H X 0.25"T







Fine Furniture for every stage of life

224404 *Mirror*

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A MIRROR

1PC

B MIRROR SUPPORT (PACKED WITH MIRROR)

2PCS

C DRESSER FROM BOX ITEM 224453

HARDWARE IDENTIFICATION

1	BOLT (M6 x 40 MM - RBW)	8PCS
2	LOCK WASHER (1/4" x 13 Ø - RBW)	8PCS
3	FLAT WASHER (1/4" x 19 Ø - RBW)	8PCS
4	ALLEN WRENCH (M4 x 65MM - BLK)	1PC


NOTE:




ASSEMBLY INSTRUCTIONS




STEP 1




STEP 2 COMPLETE





COASTERFURNITURE.COM









Fine Furniture for every stage of life

224404 *Mirror*

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A MIRROR

B MIRROR SUPPORT (PACKED WITH MIRROR)

C DRESSER FROM BOX ITEM 224453

1PC

HARDWARE IDENTIFICATION

1	BOLT (M6 x 40 MM - RBW)		8PCS
2	LOCK WASHER (1/4" x 13 Ø - RBW)		8PCS
3	FLAT WASHER (1/4" x 19 Ø - RBW)	0	8PCS
4	ALLEN WRENCH (M4 x 65MM - BLK)		1PC


NOTE:




ASSEMBLY INSTRUCTIONS




STEP 1



STEP 2 COMPLETE





COASTERFURNITURE.COM



