



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

609690LRP
LAF POWER RECLINER

ITEM :609690LRP

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

2 MINUTES

PARTS IDENTIFICATION

A BACK



1 PC

B BASE



1 PC

C PLUG-IN POWER SUPPLY




1 PC

D Y CABLE





1 PC

STEP 1




STEP 2
COMPLETE




STEP 3


OPTION1:




OPTION2:



STEP 4




STEP 5




Please follow below steps to install the 9V batteries when there is no power to operate the motion sofa.(Any model of 9V battery is applicable)

STEP 1


Open the marked battery door on the backup battery box.

**STEP 2**

Install two 9V batteries in the backup battery box.(batteries are not included)


**STEP 3**


Push the batteries in.

**STEP 4**

Close the box door.

Notice: Please don't keep the battery in the box when the power motion sofa is under daily use within power supply.





PAGE 6 OF 6



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

609690CON
CONSOLE

ITEM :609690CON

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

2 MINUTES


PARTS IDENTIFICATION

A BACK




1 PC

B BASE OF CONSOLE




1 PC


STEP 1





STEP 2



STEP 3




STEP 4
COMPLETE




STEP 5


OPTION1:




OPTION2:



STEP 6







ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

609690ARP
POWER ARMLESS RECLINER

ITEM :609690ARP

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

2 MINUTES

PARTS IDENTIFICATION

A BACK



1 PC

B BASE




1 PC

C PLUG-IN POWER SUPPLY




1 PC



STEP 1



STEP 2




STEP 3
COMPLETE




STEP 4


OPTION1:



OPTION2:




STEP 5




Please follow below steps to install the 9V batteries when there is no power to operate the motion sofa.(Any model of 9V battery is applicable)

STEP 1


Open the marked battery door on the backup battery box.

**STEP 2**

Install two 9V batteries in the backup battery box.(batteries are not included)


**STEP 3**



Push the batteries in.

**STEP 4**

Close the box door.

Notice: Please don't keep the battery in the box when the power motion sofa is under daily use within power supply.





Note: Dimension tolerance +5%



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

609690RRP
RAF POWER RECLINER

ITEM :609690RRP

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1.Remove hardware from box and sort by size.
- 2.Please check to see that all hardware and parts are present prior to start of assembly.
- 3.Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2.This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

2 MINUTES

PARTS IDENTIFICATION

A BACK




1 PC

B BASE





1 PC

STEP 1




STEP 2
COMPLETE




STEP 3


OPTION1:




OPTION2:



STEP 4




STEP 5




Please follow below steps to install the 9V batteries when there is no power to operate the motion sofa.(Any model of 9V battery is applicable)

STEP 1


Open the marked battery door on the backup battery box.

**STEP 2**

Install two 9V batteries in the backup battery box.(batteries are not included)


**STEP 3**



Push the batteries in.

**STEP 4**

Close the box door.

Notice: Please don't keep the battery in the box when the power motion sofa is under daily use within power supply.





Note: Dimension tolerance +5%