

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

724113
TV STAND

ITEM:724113



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME


60 MINUTES

MAX TV SIZE: 85"

PARTS IDENTIFICATION

A


LEFT SIDE
PANEL



1 PC

B


RIGHT SIDE
PANEL



1 PC

C


MIDDLE DIVIDER
PANEL



1 PC

D


DIVIDER PANEL



2 PCS

E


FRONT CROSS
BRACE



1 PC

F


BACK CROSS
BRACE



1 PC

G


BOTTOM PANEL



1 PC

H


ADJUSTABLE
SHELF



4 PCS

I


TOP PANEL



1 PC

J


BACK PANEL



4 PCS

K

DOOR














4 PCS

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **724113****HARDWARE IDENTIFICATION****Z**




NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		1 PC	9	HANDLE BLK		4 PCS
2	WOODEN DOWEL Ø8x30mm		34 PCS	10	HANDLE BOLT BLK		4 PCS
3	CAM BOLT Ø7x35.5mm SR		18 PCS	11	HINGE Ø35mm SR		8 PCS
4	CAM LOCK Ø15x12mm SR		18 PCS	12	HINGE SCREW Ø4x15mm SR		32 PCS
5	BOLT Ø9.5x55mm SR		6 PCS	13	FIXER		6 PCS
6	DOOR CATCH		4 PCS	14	FIXER SCREW Ø3x19mm SR		6 PCS
7	PLASTIC FEET Ø15mm		6 PCS	15	STICKER Ø20mm		3 PCS
8	PIN FOR ADJUSTABLE SHELF Ø4.9x15mm SR		16 PCS				

Z11 not included in blister packaging.**NOTE:**

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ITEM: 724113

STEP 1




ITEM: **724113**

STEP 2





STEP 3





ITEM: **724113**

COASTER
FINE FURNITURE

STEP 4




STEP 5






ITEM: **724113**

STEP 6



STEP 7



Apply glue on all wooden dowels to ensure integrity of the structure.








ITEM: **724113**

STEP 8

COASTER
FINE FURNITURE




STEP 9




ITEM: **724113**

STEP 10

COASTER
FINE FURNITURE








STEP 11



ITEM: **724113**



STEP 12

COASTER
FINE FURNITURE





STEP 13

COMPLETE



ITEM: 724113



Note : Dimension tolerance $\pm 5\%$

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

724113
TV STAND

ITEM:724113



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME


60 MINUTES

MAX TV SIZE: 85"

PARTS IDENTIFICATION

A


LEFT SIDE
PANEL



1 PC

B


RIGHT SIDE
PANEL



1 PC

C


MIDDLE DIVIDER
PANEL



1 PC

D


DIVIDER PANEL



2 PCS

E


FRONT CROSS
BRACE



1 PC

F


BACK CROSS
BRACE



1 PC

G


BOTTOM PANEL



1 PC

H


ADJUSTABLE
SHELF



4 PCS

I


TOP PANEL



1 PC

J


BACK PANEL



4 PCS

K

DOOR














4 PCS

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **724113****HARDWARE IDENTIFICATION****Z**

NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		1 PC	9	HANDLE BLK		4 PCS
2	WOODEN DOWEL Ø8x30mm		34 PCS	10	HANDLE BOLT BLK		4 PCS
3	CAM BOLT Ø7x35.5mm SR		18 PCS	11	HINGE Ø35mm SR		8 PCS
4	CAM LOCK Ø15x12mm SR		18 PCS	12	HINGE SCREW Ø4x15mm SR		32 PCS
5	BOLT Ø9.5x55mm SR		6 PCS	13	FIXER		6 PCS
6	DOOR CATCH		4 PCS	14	FIXER SCREW Ø3x19mm SR		6 PCS
7	PLASTIC FEET Ø15mm		6 PCS	15	STICKER Ø20mm		3 PCS
8	PIN FOR ADJUSTABLE SHELF Ø4.9x15mm SR		16 PCS				





Z11 not included in blister packaging.**NOTE:**

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **724113**


STEP 1

COASTER
FINE FURNITURE




ITEM: **724113**

STEP 2



STEP 3





Apply glue on all wooden dowels to ensure integrity of the structure.



ITEM: **724113**

COASTER
FINE FURNITURE

STEP 4




STEP 5






ITEM: **724113**

STEP 6



STEP 7



Apply glue on all wooden dowels to ensure integrity of the structure.








ITEM: **724113**

STEP 8

COASTER
FINE FURNITURE





STEP 9





ITEM: **724113**

STEP 10

COASTER
FINE FURNITURE








STEP 11



ITEM: **724113**



STEP 12

COASTER
FINE FURNITURE





STEP 13

COMPLETE



ITEM: 724113



Note : Dimension tolerance $\pm 5\%$

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

724114
MEDIA TOWER

ITEM:724114

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

60 MINUTES










PARTS IDENTIFICATION

A	LEFT SIDE PANEL		1 PC	G	ADJUSTABLE SHELF		1 PC
B	RIGHT SIDE PANEL		1 PC	H	FRONT TOP AND BOTTOM CROSSBAR		2 PCS
C	BOTTOM PANEL		1 PC	I	BACK CROSS BRACE		1 PC
D	LOWER CROSS PANEL		1 PC	J	LOWER BACK PANEL		1 PC
E	UPPER CROSS PANEL		2 PCS	K	UPPER BACK PANEL		3 PCS
F	TOP PANEL		1 PC	L	DOOR		1 PC

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **724114****HARDWARE IDENTIFICATION****Z**

NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		1 PC	9	HANDLE BLK		1 PC
2	WOODEN DOWEL Ø8x30mm		35 PCS	10	HANDLE BOLT BLK		1 PC
3	CAM BOLT Ø7x35.5mm SR		16 PCS	11	HINGE Ø35mm SR		2 PCS
4	CAM LOCK Ø15x12mm SR		16 PCS	12	HINGE SCREW Ø4x15mm SR		8 PCS
5	BOLT Ø9.5x55mm SR		4 PCS	13	FIXER		6 PCS
6	DOOR CATCH		1 PC	14	FIXER SCREW Ø3x19mm SR		6 PCS
7	PLASTIC FEET Ø15mm		4 PCS	15	STICKER Ø20mm		3 PCS
8	PIN FOR ADJUSTABLE SHELF Ø4.9x15mm SR		4 PCS				





Z11 not included in blister packaging.**NOTE:**

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ITEM: **724114**

STEP 1

COASTER
FINE FURNITURE



INCORRECT
CORRECT





Apply glue on all wooden dowels to ensure integrity of the structure.

ITEM: **724114**


STEP 2

COASTER
FINE FURNITURE







ITEM: **724114**

STEP 3



Apply glue on all wooden dowels to ensure integrity of the structure.

STEP 4





Apply glue on all wooden dowels to ensure integrity of the structure.

ITEM: **724114**


STEP 5

COASTER
FINE FURNITURE



Apply glue on all wooden dowels to ensure integrity of the structure.



STEP 6





ITEM: **724114**

STEP 7

COASTER
FINE FURNITURE





STEP 8






ITEM: **724114**

STEP 9

COASTER
FINE FURNITURE



STEP 10






ITEM: **724114**



STEP 11

LEFT

COASTER
FINE FURNITURE



RIGHT





ITEM: **724114**


STEP 12

LEFT


COASTER
FINE FURNITURE




RIGHT





HORIZONTAL BY
SCREW A ADJUSTMENT



LATERAL BY
SCREW B ADJUSTMENT








VERTICAL BY
SCREW C ADJUSTMENT



ITEM: **724114**


STEP 13


COASTER
FINE FURNITURE



STEP 14

COMPLETE





Note : Dimension tolerance $\pm 5\%$

ANTI-TIPPING INSTALLMENT INSTRUCTIONS


FURNITURE TIPPING RESTRAINT

WARNING

Injury may result from tipping furniture.
This restraint may protect against tipping furniture.
Do not allow children to climb on furniture.
This restraint is not a substitute for proper adult supervision.
Failure to detach this restraint before moving the furniture
may result in injury and damage.

1. To attach the anti-tip strap, securely mount one end to the top of the case piece with the 5/8" screw.
2. Position the case piece against the wall in the desired location.
3. Pull the anti-tip strap taut and mark the position of where you will secure the other end on the wall.
4. Drill a 1-1/4" hole in the spot you marked.
5. Tap in plastic wall plug.
6. Fasten anti-tip strap with wall screw provided.

(Please install the anti-tipping kit in the middle of the case piece if only have one set of anti-tipping kit.)



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

724114
MEDIA TOWER

ITEM:724114

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

60 MINUTES










PARTS IDENTIFICATION

A	LEFT SIDE PANEL		1 PC	G	ADJUSTABLE SHELF		1 PC
B	RIGHT SIDE PANEL		1 PC	H	FRONT TOP AND BOTTOM CROSSBAR		2 PCS
C	BOTTOM PANEL		1 PC	I	BACK CROSS BRACE		1 PC
D	LOWER CROSS PANEL		1 PC	JN	LOWER BACK PANEL		1 PC
E	UPPER CROSS PANEL		2 PCS	K	UPPER BACK PANEL		3 PCS
F	TOP PANEL		1 PC	L	DOOR		1 PC

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **724114****HARDWARE IDENTIFICATION****Z**

NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		1 PC	9	HANDLE BLK		1 PC
2	WOODEN DOWEL Ø8x30mm		35 PCS	10	HANDLE BOLT BLK		1 PC
3	CAM BOLT Ø7x35.5mm SR		16 PCS	11	HINGE Ø35mm SR		2 PCS
4	CAM LOCK Ø15x12mm SR		16 PCS	12	HINGE SCREW Ø4x15mm SR		8 PCS
5	BOLT Ø9.5x55mm SR		4 PCS	13	FIXER		6 PCS
6	DOOR CATCH		1 PC	14	FIXER SCREW Ø3x19mm SR		6 PCS
7	PLASTIC FEET Ø15mm		4 PCS	15	STICKER Ø20mm		3 PCS
8	PIN FOR ADJUSTABLE SHELF Ø4.9x15mm SR		4 PCS	16	PLASTIC COVER Ø 52mm		1 PC




Z11 not included in blister packaging.**NOTE:**

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ITEM: **724114**

STEP 1

COASTER
FINE FURNITURE



INCORRECT
CORRECT








Apply glue on all wooden dowels to ensure integrity of the structure.



ITEM: **724114**

STEP 2



COASTER
FINE FURNITURE




x 2




x 2



Section




INCORRECT
CORRECT



Apply glue on all wooden dowels to ensure integrity of the structure.





ITEM: **724114**

STEP 3



Apply glue on all wooden dowels to ensure integrity of the structure.

STEP 4





Apply glue on all wooden dowels to ensure integrity of the structure.

ITEM: **724114**


STEP 5

COASTER
FINE FURNITURE



Apply glue on all wooden dowels to ensure integrity of the structure.



STEP 6




ITEM: **724114**

STEP 7

COASTER
FINE FURNITURE





STEP 8






ITEM: **724114**

STEP 9

COASTER
FINE FURNITURE



STEP 10





ITEM: **724114**


STEP 11

LEFT

COASTER
FINE FURNITURE



RIGHT





ITEM: **724114**


STEP 12

LEFT


COASTER
FINE FURNITURE




RIGHT





HORIZONTAL BY
SCREW A ADJUSTMENT



LATERAL BY
SCREW B ADJUSTMENT







VERTICAL BY
SCREW C ADJUSTMENT



ITEM: **724114**


STEP 13

COASTER
FINE FURNITURE




STEP 14

COMPLETE



ITEM: 724114



Note : Dimension tolerance $\pm 5\%$

ANTI-TIPPING INSTALLMENT INSTRUCTIONS

FURNITURE TIPPING RESTRAINT


WARNING

Injury may result from tipping furniture.
This restraint may protect against tipping furniture.
Do not allow children to climb on furniture.
This restraint is not a substitute for proper adult supervision.
Failure to detach this restraint before moving the furniture may result in injury and damage.

This restraint must be screwed to a wood stud on the wall, using the long screw provided.


STEP 1

Secure the bracket to the back top of the unit, using the short screw provided, as shown in the drawing.



STEP 2

Locate the wood stud on the wall, and secure the other bracket, 2 inches below the back of the unit.



STEP 3

Place the furniture into position so both mounting brackets are vertically in line. Lace the end of the restraint strap through the larger hole in each mounting bracket. Bring both ends together and slide the flat end through the locking end, and drag it through, until the slack is removed. Ensure that the strap is securely laced and locked.

