

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life



REVISION 0 : 05/24/2016 REVISION 1 : 10/27/2016 REVISION 2 : 02/24/2020

PAGE 1 OF 6

COASTERFURNITURE.COM



ASSEMBLY TIPS:


- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.



4 WOOD RAIL (20 x 45 x 50mm)


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

2PCS




STEP 1






STEP 3






STEP 5





STEP 7



STEP 8 COMPLETE

