




ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

703798
Coffee Table

REVISION 0: 12/22/2021
REVISION 1: 08/04/2022

PAGE 1 OF 5

COASTERFURNITURE.COM

ITEM: 703798



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

15 MINUTES


PARTS IDENTIFICATION

A TOP PANEL




1PC

C LOWER SIDE PANEL




2PCS

B UPPER SIDE PANEL



2PCS


D TEMPERED GLASS



1PC

Z HARDWARE IDENTIFICATION

1 ROD



M8x370

4PCS


4 WASHER



ø25xø8.5x2

4PCS

2 WOOD DOWEL



ø8x40

8PCS

5 SCREW



M8

4PCS


3 SPRING WASHER



M8

4PCS

6 SOCKET WRENCH




M8

1PC


ITEM: 703798
ASSEMBLY INSTRUCTIONS



STEP 1




STEP 2




ITEM: 703798
ASSEMBLY INSTRUCTIONS




STEP 3



STEP 4



ITEM: 703798
ASSEMBLY INSTRUCTIONS



Note: Dimension tolerance $\pm 5\%$