

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

224393 Dresser

REVISION 0: 10/23/2023

PAGE 1 OF 4

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION

A DRESSER



1PC

B CENTER SUPPORT LEG WITH LEVELER



1PC

C ADAPTER



1PC


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ASSEMBLY INSTRUCTIONS




STEP 1



STEP 2



STEP 3 COMPLETE







ANTI-TIPPING INSTALLMENT INSTRUCTIONS FURNITURE TIPPING RESTRAINT

WARNING!

Injury may result from tipping furniture.

This restraint may protection against tipping furniture.

Do not allow children to climb on furniture.


This restraint is not a subsitute for proper adult supervision.

Failure to detach this restraint before moving the furniture may result in injury and damage.

This tip restraint must be attached to a wall stud using long screw enclosed.


STEP 1

Attach a bracket securely to the back top rail of the furniture using short screw provided, through the smaller hole.




STEP 2

Locate the other bracket on the wall over a wall stud and two inches below the mounting bracket secured to the back of the furniture. Attach the wall stud using the long screw provided, through the smaller hole.




STEP 3

Place the furniture into position so both mounting brackets are vertically in line. Lace the end of the restraint strap through the larger hole in each mounting bracket. Bring both ends together and slide the flat end through the locking end and draw it through until all slack is removed. Confirm that the strap is securely laced and locked.





Inner Size of Drawer A: 23.25"W X 9.25"D X 1.25"H X 0.50"T Inner Size of Drawer B: 25.25"W X 13.00"D X 5.00"H X 0.50"T



Note: Dimension tolerance ±5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

224394 *Mirror*

REVISION 0: 10/23/2023

PAGE 1 OF 3

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION


Α	MIRROR	1PC
В	MIRROR SUPPORT (PACKED WITH MIRROR)	2PCS
С	DRESSER FROM BOX ITEM# 224393	1PC


HARDWARE IDENTIFICATION

1	BOLT (M6 x 35mm - BLK)	8PCS
2	FLAT WASHER (M8 x 18mm - BLK)	8PCS
3	LOCK WASHER (M8 - BLK)	8PCS
4	ALLEN WRENCH (M4 x 65mm - BLK)	1PCS

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.












COASTERFURNITURE.COM





Note: Dimension tolerance ±5%