


ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

222631KW (B1-B3)
California King Storage Bed

ITEM: 222631KW (B1-B3)



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION


B1 (BOX 1)

A HEADBOARD PANEL



1PC


B FOOTBOARD FRAME



1PC


B2 (BOX 2)

E BED RAIL




2PCS

F BED SLAT




3PCS

G BED SLAT WITH MARKING




2PCS

H CONCEAL PANEL




4PCS

I CONCEAL PANEL WITH SIDE CROWN



2PCS

C RIGHT HEADBOARD LEG




1PC

D LEFT HEADBOARD LEG



1PC

J DRAWER BOTTOM TRESTLE BAR



1PC

K DRAWER SUPPORT RAIL



2PCS

L BED SLAT SUPPORT WITH LEVELER



10PCS


M DRAWER SUPPORT LEG WITH LEVELER



1PC


B3 (BOX 3)

N DRAWER BOX




2PCS

HB 222631KW(B1) FROM BOX 1 HEADBOARD COMPLETE



1PC

B 222631KW(B1) FROM BOX 1 FOOTBOARD FRAME



1PC

ITEM: 222631KW (B1-B3)



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 222631KW (B1)

1	BOLT (M6 x 30mm - BLK)		6PCS	3	FLAT WASHER (1/4" ID x 13mm - BLK)		6PCS
2	LOCK WASHER (1/4" - BLK)		6PCS	4	ALLEN WRENCH (M4 x 60mm - BLK)		1PC

Z-B2 (BOX 2) - HARDWARE PACK IS LOCATED IN 222631KW (B2)


5	FLAT HEAD SCREW (M4 x 32mm - RBW)		14PCS	9	LOCK WASHER (1/4" - BLK)		2PCS
6	PAN HEAD SCREW (M3.5 x 20mm - BLK)		30PCS	10	FLAT WASHER (1/4" ID x 13mm - BLK)		2PCS
7	SHORT BOLT (M6 x 35mm - BLK)		2PCS	11	SMALL ALLEN WRENCH (M4 x 60mm - BLK)		1PC
8	LONG BOLT (M6 x 50mm - BLK)		11PCS	12	BIG ALLEN WRENCH (M5 x 65mm - BLK)		1PC

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ASSEMBLY INSTRUCTIONS


STEP 1




****BACK VIEW****

Note : Please take note of the marking sticker (L&R) on the leg.


STEP 2



STEP 3




STEP 4




ASSEMBLY INSTRUCTIONS


STEP 5




STEP 6



STEP 7





STEP 8




ASSEMBLY INSTRUCTIONS

STEP 9



STEP 10 COMPLETE




ITEM: 222631KW (B1-B3)



Inner Size of Bed: 77.00"W X 86.00"D

Inner Size of Drawer : 23.25"W X 15.00"D X 5.00"H X 0.25"T



Note: Dimension tolerance $\pm 5\%$