

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

222831T(B1&B2) Twin Bed

REVISION 0 : 07/21/2023 REVISION 1 : 12/27/2023 REVISION 2 : 03/19/2025

PAGE 1 OF 6

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION

B1 (BOX 1) HEADBOARD 1PC **BED SLAT** 4PCS **PANEL LEFT HEADBOARD LEG** 1PC В **WOOD CLEAT** 2PCS (WITH "L" LABEL) C J 1PC **RIGHT HEADBOARD LEG** 1PC **ADAPTER PLUG** (WITH "R" LABEL) 1PC **FOOTBOARD PANEL** Ε **METAL LEG** 2PCS

B2 (BOX 2)

I BED RAIL



2PCS

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

Z-B1 (BOX 1) - HARDWARE IS LOCATED IN 222831T (B1)

1	BOLT 1 (M8 x 16MM - RBW)		8PCS	6	FLAT HEAD SCREW (M4 x 32MM - RBW)	(a) managements	8PCS
2	BOLT 2 (M8 x 35MM - RBW)	(6)	6PCS	7	SMALL ALLEN WRENCH (M4 x 65MM - BLK)		1PC
3	BOLT 3 (M6 x 35MM - RBW)	(5)	8PCS	8	BIG ALLEN WRENCH (M5 x 65MM - BLK)		1PC
4	BIG LOCK WASHER (5/16" x 14Ø - RBW)		6PCS	9	SMALL LOCK WASHER (1/4" x 12Ø - RBW)		8PCS
5	BIG FLAT WASHER (5/16" x 22Ø - RBW)		6PCS	10	SMALL FLAT WASHER (1/4" x 19Ø - RBW)		8PCS


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provided this item.

ASSEMBLY INSTRUCTIONS


COASTER

STEP 1



** BACK VIEW

STEP 2




** BACK VIEW

PAGE 4 OF 6


ASSEMBLY INSTRUCTIONS

COASTER

STEP 3



STEP 4




PAGE 5 OF 6

ASSEMBLY INSTRUCTIONS

COASTER


STEP 5 COMPLETE








Inner Size: 39.50"W X 75.00"D





ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

222832 Nightstand

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A NIGHTSTAND



1PC

B LEG



4PCS

HARDWARE IDENTIFICATION

BOLT (M6 x 16MM - RBW)



8PCS

2 ALLEN WRENCH (M4 x 110MM - BLK)




1PC


ASSEMBLY INSTRUCTIONS



STEP 1




STEP 2 COMPLETE








Inner Size of Drawer: 15.00"W X 12.25"D X 5.00"H X 0.25"T





ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

222833 Dresser

REVISION 0 : 07/21/2023 REVISION 1 : 08/21/2023

PAGE 1 OF 4

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.

BOLT

- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A DRESSER 1PC

B LEG 4PCS

C CENTER SUPPORT 1PC

HARDWARE IDENTIFICATION

2 ALLEN WRENCH
(M4 x 110MM - BLK)


1PC

8PCS


ASSEMBLY INSTRUCTIONS



STEP 1



STEP 2 COMPLETE







ANTI-TIPPING INSTALLMENT INSTRUCTIONS FURNITURE TIPPING RESTRAINT

WARNING


Injury may result from tipping furniture. This restraint may protect against tipping furniture.

Do not allow children to climb on furniture.

This restraint is not a substitute for proper adult supervision.

Failure to detach this restraint before moving the furniture may result in injury and damage.

- 1. Attach one of the mounting brackets securely to the back edge of the furniture. Use the short screw.
- 2. Determine where the furniture is to be placed and mark location on the wall for the mounting bracket screw hole approximately 2" below the bracket mounted to the edge of the furniture.
- 3. Drill a 3/16" hole in the wall. Press the plastic wall plug into the hole and gently tap until the flange on the wall plug is against the wall surface.
- 4. Position the bracket over the wall plug and use the long screw to securely attach the bracket to the wall.
- 5. Place the furniture so the bracket on the back edge is in line with the bracket on the wall.
- 6. Lace an end of the cable tie down through each bracket. Bring both ends together and slide the beaded end of the cable tie through the keyhole shaped slot on the other end until snug. Pull down on the beaded end until it snap locks into the keyhole slot.
- 7. To double lock return the beaded end back through the keyhole as shown.
- 8. Check to make sure the cable tie is securely laced and locked to the brackets.











Inner Size of Drawer : 24.50"W X 12.25"D X 5.00"H X 0.25"T





ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

222834 *Mirror*

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A MIRROR

MIRROR SUPPORT
(PACKED WITH MIRROR)

2PCS

C DRESSER
*FROM BOX ITEM 222833


HARDWARE IDENTIFICATION

1	BOLT (M6 x 40mm - RBW)	8PCS
2	LOCK WASHER (1/4" x 12ø - RBW)	8PCS
3	FLAT WASHER (1/4" x 19ø - RBW)	8PCS
4	ALLEN WRENCH (M4 x 65mm - BLK)	1PC

ASSEMBLY INSTRUCTIONS

STEP 1





STEP 2

COMPLETE

