



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

224491KE(B1-B3) ***Eastern King Bed***

ITEM: 224491KE (B1-B3)

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION


B1 (BOX 1)

A HEADBOARD
PANEL



1PC

C RIGHT
HEADBOARD LEG




1PC

B HEADBOARD BOTTOM
RAIL



1PC


D LEFT
HEADBOARD LEG



1PC

B2 (BOX 2)

E FOOTBOARD



1PC

G LEFT
FOOTBOARD LEG



1PC


F RIGHT
FOOTBOARD LEG



1PC

B3 (BOX 3)

H BED RAIL



2PCS

J BED SLAT




4PCS

I BED SLAT SUPPORT
WITH LEVELER




8PCS

HB 224491KE (B1)
FROM BOX 1
HEADBOARD
COMPLETE



1PC

FB 224491KE(B2)
FROM BOX 2
FOOTBOARD
COMPLETE



1PC

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: 224491KE (B1-B3)

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.





WARNING!







1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION






Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 224491KE (B1)

1	BOLT (Ø5/16" x 50MM- RBW)		10PCS	2	LOCK WASHER (Ø5/16" - RBW)		10PCS
3	FLAT WASHER (Ø5/16" - RBW)		10PCS	4	ALLEN WRENCH (4MM x 59MM - RBW)		1PC

Z-B2 (BOX 2) - HARDWARE PACK IS LOCATED IN 224491KE (B2)

5	BOLT (Ø5/16" x 20MM- RBW)		4PCS	6	LOCK WASHER (Ø5/16" - RBW)		4PCS
7	FLAT WASHER (Ø5/16" - RBW)		4PCS	8	ALLEN WRENCH (4MM x 59MM - RBW)		1PC

Z-B3 (BOX 3) - HARDWARE PACK IS LOCATED IN 224491KE (B3)

9	BOLT (Ø5/16" x 20MM- RBW)		8PCS	10	LOCK WASHER (Ø5/16" - RBW)		8PCS
11	FLAT WASHER (Ø5/16" - RBW)		8PCS	12	ALLEN WRENCH (4MM x 59MM - RBW)		1PC
13	FLAT HEAD SCREW (Ø4 x 30MM - RBW)		8PCS				


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ITEM: 224491KE (B1-B3)

ASSEMBLY INSTRUCTIONS

STEP 1




STEP 2




ITEM: **224491KE (B1-B3)**

ASSEMBLY INSTRUCTIONS

STEP 3




STEP 4




ITEM: **224491KE (B1-B3)**

ASSEMBLY INSTRUCTIONS

STEP 5




STEP 6 **COMPLETE**



ITEM: **224491KE (B1-B3)**



Inner Size : 81.50"W X 77.00"D



Note: Dimension tolerance $\pm 5\%$



ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE



Fine Furniture for every stage of life

224492
Nightstand

ITEM: 224492

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION

A NIGHTSTAND



1PC

B LEG



4PCS

HARDWARE IDENTIFICATION

1

BOLT
($\Phi 5/16"$ x 20mm - RBW)



12PCS

2

LOCK WASHER
($\Phi 5/16"$ - RBW)



12PCS

3

FLAT WASHER
($\Phi 5/16"$ - RBW)



12PCS

4

ALLEN WRENCH
(4mm x 59mm - RBW)




1PC

ITEM: **224492**


ASSEMBLY INSTRUCTIONS



STEP 1




STEP 2 COMPLETE



ITEM: **224492**



Inner Size of Drawer : 21.00"W X 12.25"D X 6.25"H X 0.50"T



Note: Dimension tolerance $\pm 5\%$



ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE



Fine Furniture for every stage of life

224493
Dresser

ITEM: **224493**



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION

A DRESSER



1PC

B LEG



4PCS


C CENTER SUPPORT LEG
WITH LEVELER



1PC

HARDWARE IDENTIFICATION

1 BOLT
($\Phi 5/16"$ x 20mm - RBW)



12PCS

2 LOCK WASHER
($\Phi 5/16"$ - RBW)



12PCS

3 FLAT WASHER
($\Phi 5/16"$ - RBW)




12PCS

4 ALLEN WRENCH
(4mm x 59mm - RBW)




1PC

ITEM: **224493**
ASSEMBLY INSTRUCTIONS
STEP 1



STEP 2
COMPLETE




ANTI-TIPPING INSTALLMENT INSTRUCTIONS

FURNITURE TIPPING RESTRAINT


WARNING

Injury may result from tipping furniture.
This restraint may protect against tipping furniture.
Do not allow children to climb on furniture.
This restraint is not a substitute for proper adult supervision.
Failure to detach this restraint before moving the furniture may result in injury and damage.

1. Attach one of the mounting brackets securely to the back edge of the furniture. Use the short screw.
2. Determine where the furniture is to be placed and mark location on the wall for the mounting bracket screw hole approximately 2" below the bracket mounted to the edge of the furniture.
3. Drill a 3/16" hole in the wall. Press the plastic wall plug into the hole and gently tap until the flange on the wall plug is against the wall surface.
4. Position the bracket over the wall plug and use the long screw to securely attach the bracket to the wall.
5. Place the furniture so the bracket on the back edge is in line with the bracket on the wall.
6. Lace an end of the cable tie down through each bracket. Bring both ends together and slide the beaded end of the cable tie through the keyhole shaped slot on the other end until snug. Pull down on the beaded end until it snap locks into the keyhole slot.
7. To double lock return the beaded end back through the keyhole as shown.
8. Check to make sure the cable tie is securely laced and locked to the brackets.



Inner Size of Drawer : 26.75"W X 12.25"D X 6.75"H X 0.50"T



Note: Dimension tolerance $\pm 5\%$



ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE



Fine Furniture for every stage of life

224494
Mirror

ITEM: **224494**

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

WARNING!



1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

5 MINUTES


PARTS IDENTIFICATION

A **DRESSER**
FROM BOX ITEM #224493




1PC

B **MIRROR**



1PC

C **MIRROR SUPPORT**
(PACKED WITH DRESSER)



2PCS

HARDWARE IDENTIFICATION

1 **BOLT**
(Φ1/4" x 38mm - RBW)



6PCS

2 **LOCK WASHER**
(Φ1/4" - RBW)



6PCS

3 **FLAT WASHER**
(Φ1/4" - RBW)



6PCS

4 **ALLEN WRENCH**
(4mm x 59mm - RBW)




1PC


ITEM: **224494**

ASSEMBLY INSTRUCTIONS


STEP 1



STEP 2 COMPLETE



ITEM: **224494**



Note: Dimension tolerance $\pm 5\%$