


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

224731KE (B1&B2) Eastern King Bed



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION

B1 (BOX 1)

AF	HEADBOARD PANEL	1PC	E	FOOTBOARD LEG	2PCS
В	LEFT HEADBOARD LEG (WITH "L" LABEL)	1PC	F	BED SLAT	4PCS
С	RIGHT HEADBOARD LEG (WITH "R" LABEL)	1PC	G	BED SLAT SUPPORT WITH LEVELER	8PCS
D	FOOTBOARD PANEL	1PC			

B2 (BOX 2)

H LEFT BED RAIL (WITH "H" LABEL)

1PC I RIGHT BED RAIL (WITH "I" LABEL)

1PC

NOTE:





ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

Z-B2 (BOX 2) - HARDWARE PACK IS LOCATED IN 224731KE (B2)


1	BOLT 1 (M8 x 20MM - RBW)		4PCS	7	SMALL FLAT WASHER (1/4" x 19 Ø - RBW)		6PCS
2	BOLT 2 (M8 x 35MM - RBW)	0	4PCS	8	BIG LOCK WASHER (M8 x 13MM - RBW)	Ø	4PCS
3	BOLT 4 (M6 x 35MM - RBW)	0	14PCS	9	BIG FLAT WASHER (M8 x 22MM - RBW)	0	4PCS
4	BOLT 3 (M6 x 15MM - RBW)	0)	6PCS	10	FLAT HEAD SCREW (M4 x 32MM - RBW)	3	8PCS
5	WOOD DOWEL (M10 x 30MM - RBW)		4PCS	11	SMALL ALLEN WRENCH (M4 x 100MM - BLK)		1PC
6	SMALL LOCK WASHER (1/4" x 12 Ø - RBW)		6PCS	12	BIG ALLEN WRENCH (M5 x 65MM - BLK)		1PC

NOTE:




ASSEMBLY INSTRUCTIONS

STEP 1




** BACK VIEW




COASTER

ASSEMBLY INSTRUCTIONS


STEP 3






COASTER


ASSEMBLY INSTRUCTIONS







Inner size: 76.50"W X 81.75"D



Note: Dimension tolerance ± 5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

224732 Nightstand

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A NIGHTSTAND



1PC

B METAL LEG



4PCS

HARDWARE IDENTIFICATION

1 BOLT (M6 x 15MM - RBW)



8PCS

2 FLAT WASHER (1/4" x 19MM - RBW)



8PCS

3 ALLEN WRENCH (M4 x 65MM - BLK)




1PC

NOTE:


ASSEMBLY INSTRUCTIONS



STEP 1



STEP 2




STEP 3 COMPLETE








Inner Size of Drawer: 15.00"W X 12.25"D X 5.00"H X 0.50"T



Note: Dimension tolerance ±5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

224733 Dresser

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A DRESSER



1PC

B METAL LEG



4PCS

C CENTER SUPPORT LEG WITH LEVELER



1PC


HARDWARE IDENTIFICATION

1	BOLT (M6 x 15MM - RBW)	(0)	12PCS
2	FLAT WASHER (1/4" x 19MM - RBW)		8PCS
3	ALLEN WRENCH (M4 x 65MM - BLK)		1PC


NOTE:

ASSEMBLY INSTRUCTIONS






STEP 2



STEP 3
COMPLETE







ANTI-TIPPING INSTALLMENT INSTRUCTIONS FURNITURE TIPPING RESTRAINT

WARNING

Injury may result from tipping furniture.


This restraint may protect against tipping furniture.

Do not allow children to climb on furniture.

This restraint is not a substitute for proper adult supervision.

Failure to detach this restraint before moving the furniture may result in injury and damage.


- 1. Attach one of the mounting brackets securely to the back edge of the furniture. Use the short screw.
- 2. Determine where the furniture is to be placed and mark location on the wall for the mounting bracket screw hole approximately 2" below the bracket mounted to the edge of the furniture.
- 3. Drill a 3/16" hole in the wall. Press the plastic wall plug into the hole and gently tap until the flange on the wall plug is against the wall surface.
- 4. Position the bracket over the wall plug and use the long screw to securely attach the bracket to the wall.
- 5. Place the furniture so the bracket on the back edge is in line with the bracket on the wall.
- 6. Lace an end of the cable tie down through each bracket. Bring both ends together and slide the beaded end of the cable tie through the keyhole shaped slot on the other end until snug. Pull down on the beaded end until it snap locks into the keyhole slot.
- 7. To double lock return the beaded end back through the keyhole as shown.
- 8. Check to make sure the cable tie is securely laced and locked to the brackets.








Inner Size of Drawer : 23.00"W X 12.25"D X 5.00"H X 0.50"T



Note: Dimension tolerance ±5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

224734 Mirror

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES


PARTS IDENTIFICATION

A MIRROR



1PC

B MIRROR SUPPORT (PACKED WITH MIRROR)



2PCS

C DRESSER
*FROM BOX ITEM 224733



1PC

HARDWARE IDENTIFICATION

1 BOLT (M6 x 40mm - RBW)



8PCS

2 LOCK WASHER (1/4" x 12ø - RBW)



8PCS

3 FLAT WASHER (1/4" x 19ø - RBW)



8PCS

4 ALLEN WRENCH (M4 x 65mm - BLK)




1PC

NOTE:

ASSEMBLY INSTRUCTIONS


STEP 1






STEP 2

COMPLETE









Note: Dimension tolerance ±5%