


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

225001KE
Eastern King Bed

ITEM: **225001KE**

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!












1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION

| | | | | | | | |
|----------|---|---|------------|----------|--|---|-------------|
| A | HEADBOARD PANEL |  | 1PC | G | BED RAIL (WITH "G" LABEL) |  | 2PCS |
| B | LEFT HEADBOARD LEG (WITH "L" LABEL) |  | 1PC | H | BED RAIL (WITH "H" LABEL) |  | 2PCS |
| C | RIGHT HEADBOARD LEG (WITH "R" LABEL) |  | 1PC | I | BED RAIL SUPPORT |  | 2PCS |
| D | FOOTBOARD PANEL |  | 1PC | J | BED SLAT |  | 4PCS |
| E | LEFT FOOTBOARD LEG (WITH "L" LABEL) |  | 1PC | K | BED SLAT SUPPORT WITH LEVELER |  | 8PCS |
| F | RIGHT FOOTBOARD LEG (WITH "R" LABEL) |  | 1PC | | | | |

ITEM: 225001KE

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:












1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION


| | | | | | | | |
|---|---|---|-------|----|--|---|------|
| 1 | BOLT 1 (M8 x 16MM - RBW) |  | 8PCS | 7 | SMALL LOCK WASHER (1/4" x 13Ø - RBW) |  | 4PCS |
| 2 | BOLT 2 (M8 x 25MM - RBW) |  | 8PCS | 8 | SMALL FLAT WASHER (1/4" x 19Ø - RBW) |  | 4PCS |
| 3 | BOLT 3 (M8 x 35MM - RBW) |  | 6PCS | 9 | FLAT HEAD SCREW (M4 x 32MM - RBW) |  | 8PCS |
| 4 | BIG LOCK WASHER (5/16" x 14Ø - RBW) |  | 14PCS | 10 | SMALL ALLEN WRENCH (M4 x 60MM - BLK) |  | 1PC |
| 5 | BIG FLAT WASHER (5/16" x 22Ø - RBW) |  | 14PCS | 11 | BIG ALLEN WRENCH (M5 x 68MM - BLK) |  | 1PC |
| 6 | BOLT 4 (M6 x 35MM - RBW) |  | 4PCS | | | | |

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provided this item.

ITEM: **225001KE**
ASSEMBLY INSTRUCTIONS

STEP 1




STEP 2




ITEM: **225001KE**
ASSEMBLY INSTRUCTIONS

STEP 3




STEP 4






ITEM: **225001KE**
ASSEMBLY INSTRUCTIONS



STEP 5




STEP 6
COMPLETE



ITEM: **225001KE**



Inner Size : 76.50"W X 81.00"D



Note : Dimension tolerance $\pm 5\%$

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

225002
Nightstand

ITEM: **225002**

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A NIGHTSTAND



1PC

B LEG



4PCS

HARDWARE IDENTIFICATION

1 BOLT
(M6 x 60MM - RBW)



4PCS

2 LOCK WASHER
(1/4" x 13Ø - RBW)




4PCS

3 FLAT WASHER
(1/4" x 19Ø - RBW)



4PCS

4 WOOD DOWEL
(Ø8 x 30MM)



4PCS

5 ALLEN WRENCH
(M4 x 60MM - BLK)




1PC

ITEM: **225002**



ASSEMBLY INSTRUCTIONS



STEP 1




STEP 2 COMPLETE



ITEM: **225002**



Inner Size of Drawer : 15.00"W X 12.25"D X 4.00"H X 0.50"T



Note : Dimension tolerance $\pm 5\%$

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

225003
Dresser

ITEM: **225003**

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!




1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.








ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

| | | | |
|---|---------------------------------|---|------|
| A | DRESSER |  | 1PC |
| B | LEG |  | 4PCS |
| C | CENTER SUPPORT LEG WITH LEVELER |  | 1PC |

HARDWARE IDENTIFICATION

| | | | |
|---|-----------------------------------|--|------|
| 1 | BOLT (M6 x 60MM - RBW) |  | 4PCS |
| 2 | LOCK WASHER (1/4" x 13Ø - RBW) |  | 4PCS |
| 3 | FLAT WASHER (1/4" x 19Ø - RBW) |  | 4PCS |
| 4 | WOOD DOWEL (Ø8 x 30MM) |  | 4PCS |
| 5 | ALLEN WRENCH (M4 x 60MM - BLK) |  | 1PC |


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provided this item.


ITEM: **225003**
ASSEMBLY INSTRUCTIONS



STEP 1



STEP 2
COMPLETE



ANTI-TIPPING INSTALLMENT INSTRUCTIONS

FURNITURE TIPPING RESTRAINT

WARNING

Injury may result from tipping furniture.



This restraint may protect against tipping furniture.

Do not allow children to climb on furniture.

This restraint is not a substitute for proper adult supervision.

Failure to detach this restraint before moving the furniture may result in injury and damage.


1. Attach one of the mounting brackets securely to the back edge of the furniture. Use the short screw.
2. Determine where the furniture is to be placed and mark location on the wall for the mounting bracket screw hole approximately 2" below the bracket mounted to the edge of the furniture.
3. Drill a 3/16" hole in the wall. Press the plastic wall plug into the hole and gently tap until the flange on the wall plug is against the wall surface.
4. Position the bracket over the wall plug and use the long screw to securely attach the bracket to the wall.
5. Place the furniture so the bracket on the back edge is in line with the bracket on the wall.
6. Lace an end of the cable tie down through each bracket. Bring both ends together and slide the beaded end of the cable tie through the keyhole shaped slot on the other end until snug. Pull down on the beaded end until it snap locks into the keyhole slot.
7. To double lock return the beaded end back through the keyhole as shown.
8. Check to make sure the cable tie is securely laced and locked to the brackets.



ITEM: **225003**




Inner Size of Drawer : 23.25"W X 12.25"D X 5.00"H X 0.50"T



Note : Dimension tolerance $\pm 5\%$

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

225004
Mirror

ITEM: **225004**

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A MIRROR



1PC

**B MIRROR SUPPORT
(PACKED WITH MIRROR)**



2PCS

**C DRESSER
*FROM BOX ITEM 225003**



1PC

HARDWARE IDENTIFICATION

**1 BOLT
(M6 x 40MM - RBW)**



8PCS

**2 LOCK WASHER
(1/4" x 13Ø - RBW)**



8PCS

**3 FLAT WASHER
(1/4" x 19Ø - RBW)**



8PCS

**4 ALLEN WRENCH
(M4 x 60MM - BLK)**




1PC

ITEM: **225004**



ASSEMBLY INSTRUCTIONS




STEP 1



STEP 2 COMPLETE



ITEM: **225004**



Note : Dimension tolerance $\pm 5\%$