



ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE



Fine Furniture for every stage of life

225011Q (B1&B2)
Queen Bed

ITEM: 225011Q (B1&B2)



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.










ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION

B1 (BOX 1)

A	HEADBOARD PANEL		1PC
B	FOOTBOARD PANEL		1PC
C	TOP PANEL		2PCS
D	LEG		4PCS
E	CROSSBAR		2PCS
F	ROLL SLAT (20PCS)		1SET
G	CENTER RAIL SUPPORT WITH LEVELER		3PCS

B2 (BOX 2)

H	BED RAIL		2PCS
I	CENTER RAIL		1PC

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: 225011Q (B1&B2)



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.














WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 225011Q (B1)

1	SHORT BOLT (M8 x 20mm - RBW)		8PCS
2	MEDIUM BOLT (M6 x 35mm - BLK)		8PCS
3	LONG BOLT (M6 x 60mm - BLK)		4PCS
4	LOCK WASHER (M6 - BLK)		12PCS
5	SMALL FLAT WASHER (M6 x 13mm - BLK)		12PCS
6	BIG FLAT WASHER (M8 x 18mm - RBW)		8PCS
7	PAN HEAD SCREW (M4 x 30mm - BLK)		76PCS
8	BARREL NUT (M6 x 13mm - SLV)		4PCS
9	WOOD DOWEL (M8 x 30mm - NAT)		4PCS
10	SMALL ALLEN WRENCH (M4 x 65mm - BLK)		1PC
11	BIG ALLEN WRENCH (M5 x 65mm - BLK)		1PC

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: 225011Q (B1&B2)




ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2




ITEM: 225011Q (B1&B2)




ASSEMBLY INSTRUCTIONS

STEP 3



STEP 4




ITEM: **225011Q (B1&B2)**


ASSEMBLY INSTRUCTIONS



STEP 5




STEP 6 COMPLETE



ITEM: **225011Q (B1&B2)**



Inner Size : 61.00"W x 81.00"D



Note : Dimension tolerance $\pm 5\%$



ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE



Fine Furniture for every stage of life

225012
Nightstand

ITEM:225012



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A NIGHTSTAND



1PC

B LEG



2PCS


C CROSSBAR



1PC


HARDWARE IDENTIFICATION

1 SHORT BOLT
(M6 x 35mm - BLK)



6PCS

2 LONG BOLT
(M6 x 60mm - BLK)



2PCS

3 U WASHER
(M6 - RBW)



4PCS

4 LOCK WASHER
(M6 - BLK)



4PCS

5 FLAT WASHER
(M6 x 13mm - BLK)



4PCS

6 BARREL NUT
(M6 x 13mm - SR)



2PCS

7 BIG WOOD DOWEL
(M10 x 30mm - NTL)



4PCS

8 SMALL WOOD DOWEL
(M8 x 30mm - NTL)



2PCS

9 ALLEN WRENCH
(M4 x 110mm - BLK)




1PC


ITEM: **225012**
ASSEMBLY INSTRUCTIONS





STEP 1



STEP 2




STEP 3
COMPLETE



ITEM: **225012**



Inner Size of Drawer : 24.50"W X 12.75"D X 5.00"H X 0.50"T



Note : Dimension tolerance $\pm 5\%$



ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE



Fine Furniture for every stage of life

225013
Dresser

ITEM: 225013



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A DRESSER



1PC

B LEG



2PCS


C CROSSBAR



1PC


HARDWARE IDENTIFICATION

1 SHORT BOLT
(M6 x 35mm - BLK)



7PCS

2 LONG BOLT
(M6 x 60mm - BLK)



2PCS

3 U WASHER
(M6 - RBW)



4PCS

4 LOCK WASHER
(M6 - BLK)



5PCS

5 FLAT WASHER
(M6 x 13mm - BLK)



5PCS

6 BARREL NUT
(M6 x 13mm - SR)



2PCS

7 BIG WOOD DOWEL
(M10 x 30mm - NTL)



4PCS

8 SMALL WOOD DOWEL
(M8 x 30mm - NTL)



2PCS

9 ALLEN WRENCH
(M4 x 110mm - BLK)




1PCS


ITEM: **225013**
ASSEMBLY INSTRUCTIONS





STEP 1



STEP 2



STEP 3
COMPLETE



ANTI-TIPPING INSTALLATION INSTRUCTIONS

FURNITURE TIPPING RESTRAINT

WARNING

Injury may result from tipping furniture.




This restraint may protect against tipping furniture.

Do not allow children to climb on furniture.

This restraint is not a substitute for proper adult supervision.

Failure to detach this restraint before moving the furniture may result in injury and damage.


1. Attach one of the mounting brackets securely to the back edge of the unit, using the short screw.
2. Determine where the unit is to be placed, and mark the location on the wall for the other mounting bracket. The bracket on the wall needs to be approximately 2" below the bracket mounted to the edge of the unit.
3. Drill a hole in the wall. Insert the plastic wall anchor into the hole and if necessary, use a small block of wood and hammer to tap it in so that it's flush with the wall.
4. Attach the bracket over the plastic wall anchor using the long screw.
5. Place the unit against the wall, both brackets need to be facing each other.
6. Lace an end of the restraint strap through the hole in each bracket. Bring both ends together and rotate the thumb nut onto the threaded end until tight.
7. Ensure that the restraint strap is securely laced and locked.



ITEM: **225013**




Inner Size of Drawer : 29.00"W X 12.75"D X 6.25"H X 0.50"T



Note : Dimension tolerance $\pm 5\%$

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

225014
Mirror

ITEM: **225014**



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A MIRROR




1PC

B MIRROR SUPPORT
(PACKED WITH MIRROR)



2PCS


C DRESSER
FROM BOX ITEM# 225013



1PC

HARDWARE IDENTIFICATION

1 BOLT
(M6 x 35mm - BLK)



8PCS

2 FLAT WASHER
(M8 x 18mm - BLK)



8PCS

3 LOCK WASHER
(M8 - BLK)



8PCS

4 ALLEN WRENCH
(M4 - BLK)




1PC

ITEM: **225014**




ASSEMBLY INSTRUCTIONS

STEP 1




BACK VIEW


STEP 2



STEP 3 COMPLETE



ITEM: **225014**



Note : Dimension tolerance $\pm 5\%$