

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

950429
ACCENT CABINET

ITEM:950429



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME


30 MINUTES

PARTS IDENTIFICATION


A LEFT SIDE PANEL 1 PC




B RIGHT SIDE PANEL 1 PC




C MIDDLE DIVIDER PANEL 1 PC




D LONG CROSS BRACE 2 PCS




E SHORT CROSS BRACE 2 PCS




F BOTTOM PANEL 1 PC




G TOP PANEL 1 PC




H BACK PANEL 2 PCS



I GLASS DOOR 2 PCS









J ADJUSTABLE SHELF 2 PCS



NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **950429****HARDWARE IDENTIFICATION****Z**

NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		1 PC	8	HINGE Ø35mm SR		4 PCS
2	WOODEN DOWEL Ø8x30mm		26 PCS	9	HINGE SCREW Ø 4x15mm SR		16 PCS
3	CAM BOLT Ø7x35.5mm SR		14 PCS	10	HANDLE		2 PCS
4	CAM LOCK Ø15x12mm SR		14 PCS	11	HANDLE BOLT Ø4x25mm SR		2 PCS
5	SCREW Ø4.5x42mm SR		6 PCS	12	FIXER		6 PCS
6	PLASTIC FEET Ø15mm		4 PCS	13	FIXER SCREW Ø 3x19mm SR		6 PCS
7	PIN Ø5x20.5mm SR		8 PCS	14	STICKER Ø20mm		3 PCS






Z8 not included in blister packaging.**NOTE:**

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **950429**

STEP 1






COASTER
FINE FURNITURE





Apply glue on all wooden dowels to ensure integrity of the structure.

ITEM:950429

STEP 2





STEP 3






ITEM: **950429**

STEP 4

COASTER
FINE FURNITURE






STEP 5




ITEM: **950429**

STEP 6

COASTER
FINE FURNITURE




STEP 7





ITEM: **950429**

COASTER
FINE FURNITURE

STEP 8







STEP 9





ITEM: **950429**

STEP 10

COASTER
FINE FURNITURE






STEP 11





ITEM: **950429**

STEP 12

COASTER
FINE FURNITURE





STEP 13







ITEM: **950429**

STEP 14


COASTER
FINE FURNITURE




STEP 15




HORIZONTAL BY
SCREW A ADJUSTMENT



LATERAL BY
SCREW B ADJUSTMENT







VERTICAL BY
SCREW C ADJUSTMENT







ITEM: **950429**

STEP 16

COASTER
FINE FURNITURE



STEP 17






ITEM: **950429**





STEP 18

COMPLETE



ITEM: **950429**

COASTER
FINE FURNITURE



Note : Dimension tolerance $\pm 5\%$


ANTI-TIPPING INSTALLMENT INSTRUCTIONS
FURNITURE TIPPING RESTRAINT**WARNING**

Injury may result from tipping furniture.
This restraint may protect against tipping furniture.
Do not allow children to climb on furniture.
This restraint is not a substitute for proper adult supervision.
Failure to detach this restraint before moving the furniture may result in injury and damage.


This restraint must be screwed to a wood stud on the wall, using the long screw provided.

STEP 1

Secure the bracket to the back top of the unit, using the short screw provided, as shown in the drawing.

**STEP 2**

Locate the wood stud on the wall, and secure the other bracket, 2 inches below the back of the unit.

**STEP 3**

Place the furniture into position so both mounting brackets are vertically in line. Lace the end of the restraint strap through the larger hole in each mounting bracket. Bring both ends together and slide the flat end through the locking end, and drag it through, until the slack is removed. Ensure that the strap is securely laced and locked.

