


ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

100063
Metal Table

ITEM:100063



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING !


1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.



ASSEMBLY TIME

15 MINUTE

PARTS IDENTIFICATION



HARDWARE IDENTIFICATION

1	BOLT (1/4"x1-1/4" - BLK)		8PCS	5	WASHER (ϕ 15mm - BLK)		2PCS
2	WASHER (ϕ 16mm - BLK)		8PCS	6	ALLEN KEY (4x22X60mm - BLK)		1PC
3	NUT (ϕ 3/8" - BLK)		2PCS	7			1PC
4	WASHER (ϕ 20mm - BLK)		2PCS	8			1PC

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **100063**




ASSEMBLY INSTRUCTIONS

STEP 1:

ASSEMBLY

Do not fully tighten all bolts until assembly is complete.
This will help all parts to assemble properly.


3		1pc
4		1pc
5		1pc
7		
8		



PLEASE FULL TIGHTEN THE NUT

STEP 2:


3		1pc
4		1pc
5		1pc
7		
8		




ITEM: **100063**

ASSEMBLY INSTRUCTIONS

STEP 3:




STEP 4:



ITEM: **100063**

COASTER[®]
FINE FURNITURE



Note : Dimension tolerance $\pm 5\%$