


## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



*Fine Furniture for every stage of life*

# 100611 *Dining Table*

REVISION 0 : 01/05/2019  
REVISION 1 : 07/08/2019  
REVISION 2 : 11/03/2021  
REVISION 3: 08/31/2022

ITEM: **100611**



## ASSEMBLY INSTRUCTIONS


### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

15 MINUTES

## PARTS IDENTIFICATION

A


TABLE TOP



1PC





B

TABLE LEG



4PCS

**HARDWARE IDENTIFICATION**


1	<b>BOLT</b> (5/16 x 50 x 13mm - BLK)		8PCS
2	<b>SPRING WASHER</b> (5/16 - BLK)		8PCS
3	<b>FLAT WASHER</b> (5/16 x 19mm - BLK)		8PCS
4	<b>ALLEN WRENCH</b> (5/16 x 64 x 25mm - BLK)		1PC

ITEM: 100611


ASSEMBLY INSTRUCTIONS



STEP 1



STEP 2  
COMPLETE





## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



*Fine Furniture for every stage of life*

# 100612 Dining Chair

REVISION 0 : 01/05/2019  
REVISION 1 : 08/31/2022  
REVISION 2 : 11/15/2023  
REVISION 3 : 04/12/2024  
REVISION 4 : 06/29/2024

ITEM: **100612**



## ASSEMBLY INSTRUCTIONS


### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

10 MINUTES

## PARTS IDENTIFICATION

A


CHAIR BACK



1 PC

B


CUSHION SEAT



1 PC

C


LEFT LEG



1 PC

D


RIGHT LEG



1 PC

E

FRONT STRETCHER



1 PC

### NOTE:




Quantities shown are for one chair.

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **100612**



## HARDWARE IDENTIFICATION

1	<b>BOLT</b> (1/4 x 16mm - BLK)		6 PCS
2	<b>SPRING WASHER</b> (M5 x 15mm - BLK)		4 PCS
3	<b>ALLEN WRENCH</b> (1/4 x 64 x 22mm - BLK)		1PC

**NOTE:**

Quantities shown are for one chair.


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **100612**




## ASSEMBLY INSTRUCTIONS

### STEP 1



### STEP 2





ITEM: 100612

## ASSEMBLY INSTRUCTIONS

### STEP 3

COMPLETE

