



ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE



Fine Furniture for every stage of life

100771
Dining Table

REVISION 0: 01/10/2006
REVISION 1: 02/20/2012
REVISION 2: 11/19/2020

COASTERFURNITURE.COM

ITEM: **100771**



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS :

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING !

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

10 MINUTES


PARTS IDENTIFICATION

A TOP



1PC


B LEG



4PCS

HARDWARE IDENTIFICATION

1 WRENCH
(12.8MM - RBW)



1PC

2 HEX NUT
(5/16" - RBW)



8PCS

3 LOCK WASHER
(5/16" - RBW)



8PCS

4 FLAT WASHER
(5/16" - RBW)




8PCS

ITEM: **100771**





ASSEMBLY INSTRUCTIONS


STEP 1



STEP 2 COMPLETE



ITEM: **100771**



Note: Dimension tolerance $\pm 5\%$



ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE



Fine Furniture for every stage of life

100772
Dining Side Chair

REVISION 0: 01/10/2006
REVISION 1: 02/07/2012
REVISION 2: 10/10/2019

PAGE 1 OF 4

COASTERFURNITURE.COM

ITEM: **100772**



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS :

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING !





1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.







ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

| | | | |
|---|-----------------|--|------|
| A | BACK FRAME |  | 1PC |
| B | FRONT LEG FRAME |  | 1PC |
| C | SIDE RAIL |  | 2PCS |
| D | SEAT CUSHION |  | 1PC |

HARDWARE IDENTIFICATION

| | | | |
|---|------------------------------------|--|------|
| 1 | ALLEN WRENCH (M4 x 110mm - BLK) |  | 1PC |
| 2 | BOLT (M6 x 50mm - RBW) |  | 6PCS |
| 3 | LOCK WASHER (1/4" - BLK) |  | 6PCS |
| 4 | PAN HEAD SCREW (#8 x 1" - BLK) |  | 4PCS |

NOTE :


Phillips head screw driver is required in the assembly process. However, manufacturer does not provide this item. Quantities shown are for one chair.

ITEM: **100772**


ASSEMBLY INSTRUCTIONS



STEP 1



STEP 2




ITEM: **100772**



ASSEMBLY INSTRUCTIONS




STEP 3



STEP 4 **COMPLETE**



ITEM: **100772**



Note: Dimension tolerance $\pm 5\%$