

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

100515GRY DINING CHAIR

REVISION 0 : 10/09/2019 REVISION 1 : 03/09/2023 REVISION 2 : 16/11/2023 REVISION 3 : 24/01/2024

PAGE 1 OF 4

COASTERFURNITURE.COM

ITEM: 100515GRY

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:


- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



- Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
 This product is for home use only and not intended for commercial establishments.



PARTS IDENTIFICATION



HARDWARE PACKAGE

- ALLEN WRENCH (Ø1/4"*57mm-SILVER)

1PCS

3. **ALLEN BOLT** (Ø1/4"*15mm-SILVER)



4PCS

2. **ALLEN BOLT** (Ø1/4"*10mm-SILVER)




4 PCS

NOTE: QUANTITIES SHOWN ARE FOR ONE CHAIR


ITEM: **100515GRY** ASSEMBLY INSTRUCTIONS



STEP 1



STEP 2 COMPLETE




PAGE 3 OF 4

COASTERFURNITURE.COM

ITEM: **100515GRY** ASSEMBLY INSTRUCTIONS



STEP 3 COMPLETE





ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

102310(B1-B2) DINING TABLE

PAGE 1 OF 4

ITEM: 102310(B1-B2)

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.




WARNING !

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME 15 MINUTES

PARTS IDENTIFICATION




HARDWARE PACKAGE


Z-B2 (BOX 2)-HARDWARE PACK IS LOCATED IN 102310(B2)



PAGE 2 OF 4

COASTERFURNITURE.COM





ITEM: 102310(B1-B2)

COASTER

ASSEMBLY INSTRUCTIONS

STEP 3
COMPLETE

