

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

100515WHT DINING CHAIR

REVISION 0 : 10/09/2019 REVISION 1 : 03/09/2023 REVISION 2 : 16/11/2023 REVISION 3 : 24/01/2024

PAGE 1 OF 4

COASTERFURNITURE.COM

ITEM: 100515WHT

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!


- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION



HARDWARE PACKAGE

1. ALLEN WRENCH 1PC 3. ALLEN BOLT 4PCS (Ø1/4"*57mm-SILVER) 4PCS

2. ALLEN BOLT 4PCS

NOTE: QUANTITIES SHOWN ARE FOR ONE CHAIR


(Ø1/4"*10mm-SILVER)

ITEM: 100515WHT


ASSEMBLY INSTRUCTIONS



STEP 1



STEP 2 COMPLETE




PAGE 3 OF 4

COASTERFURNITURE.COM

ITEM: **100515WHT**ASSEMBLY INSTRUCTIONS



STEP 3
COMPLETE





ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

102310(B1-B2) DINING TABLE

PAGE 1 OF 4

ITEM: 102310(B1-B2)

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.




WARNING !

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME 15 MINUTES

PARTS IDENTIFICATION




HARDWARE PACKAGE


Z-B2 (BOX 2)-HARDWARE PACK IS LOCATED IN 102310(B2)



PAGE 2 OF 4

COASTERFURNITURE.COM





ITEM: 102310(B1-B2)

COASTER

ASSEMBLY INSTRUCTIONS

STEP 3 COMPLETE

