

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

102721 Dining Table

REVISION 0: 06/19/2011 REVISION 1: 09/13/2011 REVISION 2: 05/05/2020

PAGE 1 OF 3

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

10 MINUTES


PARTS IDENTIFICATION

A TOP



1PC

B LEG



4PCS


HARDWARE IDENTIFICATION

1	WRENCH (12.8MM - RBW)	1PC
2	HEX BOLT (M8 x 60MM - SILVER)	8PCS
3	LOCK WASHER (5/16" - RBW)	8PCS
4	FLAT WASHER (5/16" - RBW)	8PCS


ASSEMBLY INSTRUCTIONS



STEP 1




STEP 2 COMPLETE









Note: Dimension tolerance ±5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

102722 Dining Side Chair

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A	BACK FRAME	1PC
В	FRONT LEG FRAME	1PC
С	SIDE RAIL	2PCS
D	SEAT CUSHION	1PC
E1	RIGHT STRETCHER	1PC
F1	LEFT STRETCHER	1PC

HARDWARE IDENTIFICATION

1	ALLEN WRENCH (M4 x 110mm - BLK)		1PC
2	BOLT (M6 x 50mm - RBW)		6PCS
3	LOCK WASHER (1/4" - BLK)		6PCS
4	SHORT PAN HEAD SCREW (#8 x 1" - BLK)	<i>₹₩₩₩</i>	4PCS
5	LONG PAN HEAD SCREW (#8 x 1 1/2" - BLK)	<i>∞ammmm</i> (⊕	4PCS


NOTE:


Phillips head screw driver is required in the assembly process. However, manufacturer does not provide this item. Quantities shown are for one chair.

ITEM: 102722 ASSEMBLY INSTRUCTIONS



STEP 1







ASSEMBLY INSTRUCTIONS




STEP 3




STEP 4 COMPLETE









Note: Dimension tolerance ±5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

102723 <u>Bench</u>

REVISION 0: 07/27/2011 REVISION 1: 09/21/2018 REVISION 2:12/13/2020

COASTERFURNITURE.COM



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

8 MINUTES

PARTS IDENTIFICATION

A SEAT CUSHION WITH FRAME



1PC

B LEG



4PCS


HARDWARE IDENTIFICATION

1	WRENCH (12.8mm - RBW)	1PC
2	BOLT (M8 x 60mm - SILVER)	8PCS
3	LOCK WASHER (5/16" - RBW)	8PCS
4	FLAT WASHER (5/16" - RBW)	8PCS


COASTER


ASSEMBLY INSTRUCTIONS

STEP 1




STEP 2 COMPLETE









Note: Dimension tolerance ±5%