


**ASSEMBLY INSTRUCTIONS**  
**COASTER FINE FURNITURE**



*Fine Furniture for every stage of life*

**105761(B1-B2)**  
***DINING TABLE***

# ITEM: 105761(B1-B2)



## ASSEMBLY INSTRUCTIONS


### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING !

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME

10 MINUTE

## PARTS IDENTIFICATION

### B1 (BOX 1)


A GLASS TOP



1PC


### B2 (BOX 2)

B BASE 1




1PC

C BASE 2



1PC







D METAL PLATE



1PC

## HARDWARE IDENTIFICATION

Z-B2 (BOX 2) - HARDWARE PACK IS LOATED IN 105761 (B2)

1	BOLT (1/4"x3/4")		6PCS	4	WASHER (ø16mm)		6PCS
2	BOLT (1/4"x1/2")		4PCS	5	ALLEN KEY (4x22x60mm)		1PC
3	NUT (ø1/4")		6PCS	6	WRENCH		1PC

ITEM: **105761(B1-B2)**




## ASSEMBLY INSTRUCTIONS

### STEP 1:

#### NOTE:


Please put all parts on a non-abrasive floor before assembly, and follow assembly steps to assemble your newly purchased product correctly and efficiently.




ITEM: **105761(B1-B2)**

## ASSEMBLY INSTRUCTIONS

### STEP 2:




### STEP 3:






ITEM: **105761(B1-B2)**  
**ASSEMBLY INSTRUCTIONS**  
**STEP 4:**




1  6PCS




**STEP 5:**

3  6PCS  
4  6PCS  
6 




ITEM: **105761(B1-B2)**



**Note :** Dimension tolerance  $\pm 5\%$

**ASSEMBLY INSTRUCTIONS**  
**COASTER FINE FURNITURE**



*Fine Furniture for every stage of life*

**105782/105762**  
**ARM CHAIR**

ITEM: **105782/105762**



## ASSEMBLY INSTRUCTIONS

### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.




### WARNING !

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.






ASSEMBLY TIME

15 MINUTE

## PARTS IDENTIFICATION



## HARDWARE IDENTIFICATION

1	BOLT (1/4"x1/2" - BLK)		8PCS	4	WASHER (ø16mm - BLK)		16PCS
2	BOLT (1/4"x3/4" - BLK)		8PCS	5	ALLEN KEY (4x22X60mm - BLK)		1PC
3	WASHER		16PCS				

### NOTE:

Quantities shown are for one chair.




ITEM: **105782/105762**  
**ASSEMBLY INSTRUCTIONS**  
**STEP 1:**








**ASSEMBLY**

Do not fully tighten all bolts until assembly is complete.  
This will help all parts to assemble properly.



**STEP 2:**


1		8PCS
4		8PCS
3		8PCS
5		




ITEM: **105782/105762**

## ASSEMBLY INSTRUCTIONS

### STEP 3:




### STEP 4:



ITEM: **105782/105762**

## ASSEMBLY INSTRUCTIONS

### STEP 5:



**Note :** Dimension tolerance  $\pm 5\%$