



ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE



Fine Furniture for every stage of life

106412
Side Chair

ITEM: 106412



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!




1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.









ASSEMBLY TIME

8 MINUTES

PARTS IDENTIFICATION

A	BACK FRAME		1PC
B	SEAT CUSHION		1PC
C	FRONT LEG		2PCS

HARDWARE IDENTIFICATION

1	SHORT BOLT (M6 x 40MM -RBW)		2PCS
2	MEDIUM BOLT (M6 x 60MM -RBW)		4PCS
3	LONG BOLT (M6 x 80MM -RBW)		4PCS
4	LOCK WASHER (M6 x 12MM -RBW)		10PCS
5	FLAT WASHER (M6 x 19MM -RBW)		10PCS
6	ALLEN WRENCH (M4 x 100MM -BLK)		1PC

NOTE:


Quantities shown are for one chair.

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ITEM: **106412**
ASSEMBLY INSTRUCTIONS





STEP 1




STEP 2



STEP 3
COMPLETE



ITEM: **106412**



Note: Dimension tolerance $\pm 5\%$