



ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE



Fine Furniture for every stage of life

106440

DINING TABLE

REVISION 0 : 08/18/2017
REVISION 1 : 12/10/2024

PAGE 1 OF 5

COASTERFURNITURE.COM

ITEM:106440

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



- WARNING!
1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION

B1: Top


A GLASS



1PC

B2: Base

B LEG



4PCS

Z

HARDWARE IDENTIFICATION

1 SHORT BOLT
(5/16" x 10mm SR)



4PCS

2 LONG BOLT
(5/16" x 63mm SR)



4PCS

3 LEVELER
(5/16" x 18mm BLK)



4PCS

4 CAP
(25 x 50mm SR)



4PCS

5 WASHER
(ø19mm SR)



4PCS

6 ALLEN WRENCH
(4mm)



1PC

HARDWARE PACK IS LOCATED IN 106440B2


ITEM:106440




ASSEMBLY INSTRUCTIONS

STEP 1

Do not tighten until each step is completed or instructed.




STEP 2




ITEM: 106440

ASSEMBLY INSTRUCTIONS



STEP 3



STEP 4



COMPLETE




ITEM:106440

ASSEMBLY INSTRUCTIONS



Product Size : 1168 DIA X 750H (MM)

Product Size : 46" DIA X 29 ½"




Note : Dimension tolerance $\pm 5\%$



ASSEMBLY INSTRUCTIONS

COASTER FINE FURNITURE



121572
Dining Chair

ITEM:121572



ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.





WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.






ASSEMBLY TIME	3 MINUTES
---------------	-----------

PARTS IDENTIFICATION

	PART NAME	FIGURE	QTY
A	SEAT		1PC
B	LEG		1PC

HARDWARE IDENTIFICATION


	HARDWARE NAME		FIGURE	QTY
1	BOLT	φ8x40mm		4PCS
2	WASHER	φ18mm		4PCS
3	ALLEN WRENCH	φ5mm		1PC

ITEM:121572




ASSEMBLY INSTRUCTIONS



STEP 1




STEP 2



ITEM:121572

ASSEMBLY INSTRUCTIONS



COASTERFURNITURE.COM