

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

107452
Side Chair

ITEM: **107452**



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A BACK FRAME



1PC

C FRONT LEG



2PCS


B SEAT CUSHION
WITH FRAME



1PC

HARDWARE IDENTIFICATION

1 LONG BOLT
(Ø5/16" x 75mm - RBW)




4PCS

4 LOCK WASHER
(Ø5/16" - RBW)



10PCS

2 MEDIUM BOLT
(Ø5/16" x 50mm - RBW)



4PCS

5 FLAT WASHER
(Ø5/16" x 19 x 1.5mm - RBW)



10PCS

3 SHORT BOLT
(Ø5/16" x 38mm - RBW)



2PCS

6 ALLEN WRENCH
(74 x 30 x 4mm - RBW)



1PC

NOTE :


Quantities shown are for one chair.

ITEM: **107452**




ASSEMBLY INSTRUCTIONS

STEP 1




STEP 2



ITEM: **107452**



ASSEMBLY INSTRUCTIONS

STEP 3




STEP 4

COMPLETE



ITEM: **107452**



Note: Dimension tolerance $\pm 5\%$