




ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

107551
Dining Table

ITEM: **107551**

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

5 MINUTES


PARTS IDENTIFICATION

A TOP




1PC

B LEG



4PCS

C LEAF




1PC

HARDWARE IDENTIFICATION

1

BOLT
(Φ5/16" x 65mm - RBW)



8PCS

2

LOCK WASHER
(Φ5/16" - RBW)



8PCS

3

FLAT WASHER
(Φ5/16" - RBW)



8PCS

4

ALLEN WRENCH
(4MM - RBW)




1PC


ITEM: **107551**

ASSEMBLY INSTRUCTIONS

STEP 1




STEP 2




ITEM: **107551**

ASSEMBLY INSTRUCTIONS


STEP 3



STEP 4 COMPLETE



ITEM:107551



Note: Dimension tolerance $\pm 5\%$



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

107552
Dining Side Chair

ITEM: **107552**



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

5 MINUTES


PARTS IDENTIFICATION

A BACK FRAME




1PC

B SEAT CUSHION
WITH FRAME



1PC


C FRONT LEG



2PCS


HARDWARE IDENTIFICATION

1 SHORT BOLT
($\Phi 5/16"$ x 50mm - RBW)



5PCS

2 LONG BOLT
($\Phi 5/16"$ x 70mm - RBW)



4PCS

3 LOCK WASHER
($\Phi 5/16"$ - RBW)



9PCS

4 FLAT WASHER
($\Phi 5/16"$ - RBW)



9PCS

5 ALLEN WRENCH
(4MM - RBW)




1PC


ITEM: **107552**

ASSEMBLY INSTRUCTIONS


STEP 1



STEP 2



ITEM: **107552**



Note: Dimension tolerance $\pm 5\%$



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

107553
DiningArm Chair

ITEM: **107553**



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

5 MINUTES


PARTS IDENTIFICATION

A BACK FRAME




1PC

B SEAT CUSHION
WITH FRAME




1PC

C FRONT LEG




2PCS

D RIGHT ARM



1PC


E LEFT ARM



1PC


HARDWARE IDENTIFICATION

1 MEDIUM BOLT
($\Phi 5/16"$ x 50 mm - RBW)




5PCS

2 LONG BOLT
($\Phi 5/16"$ x 70 mm - RBW)



4PCS

3 SHORT BOLT
($\Phi 5/16"$ x 40 mm - RBW)



2PCS

4 LOCK WASHER
($\Phi 5/16"$ - RBW)



11PCS

5 FLAT WASHER
($\Phi 5/16"$ - RBW)




11PCS

6 ALLEN WRENCH
(4MM - RBW)



1PC

7 FLAT HEAD SCREW
($\Phi 4$ x 50mm - NK)




2PCS


ITEM: **107552**

ASSEMBLY INSTRUCTIONS

STEP 1




STEP 2




ITEM: **107553**

ASSEMBLY INSTRUCTIONS


STEP 3



STEP 4 COMPLETE



ITEM: **107553**



Note: Dimension tolerance $\pm 5\%$