

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

107872N Dining chair

REVISION 0: 08/20/2019 REVISION 1: 11/01/2023 REVISION 2: 11/15/2023 REVISION 3: 12/31/2024

ITEM: 107872N (B1-B2)

COASTER

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

<u>B1 (BOX 1)</u>

BACK



B2 (BOX 2)



NOTE:

Quantities shown are for on chair

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

PAGE 2 OF 5

ITEM:107872N (B1-B2)

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

Z-B2 (BOX 2) - HARDWARE PACK IS LOCATED IN 107872N (B2)

1	ALLEN WRENCH (65 x 64MM - RBW)		1PC
2	SHORT BOLT (M8*25mm)		4PCS
3	Spring Shim	0	4PCS
4	BARREL NUT (Dia10mm)		4PCS

Hardware pack is located in 107872N B2

NOTE:


Quantities shown are for on chair

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM:107872N (B1-B2) **ASSEMBLY INSTRUCTIONS** STEP 1 STEP 2 PAGE 4 OF 5 COASTERFURNITURE.COM

ITEM:107872N (B1-B2)





Note: Dimension tolerance $\pm 5\%$



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

107891 Dining Table

REVISION 0 : 05/16/2019 REVISION 1 : 09/27/2022 REVISION 2 : 02/14/2023 REVISION 2 : 03/14/2023

ITEM: 107891 (B1-B3)



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION

B1 (BOX 1)

B3 (BOX 3)

A MARBLE TOP



1PC

BASE



1PC

B2 (BOX 2)

B TOP FRAME



1PC

C PEDESTAL



4PCS

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

PAGE 2 OF 5

ITEM:107891 (B1-B3)

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

Z-B2 (BOX 2) - HARDWARE PACK IS LOCATED IN 107872N (B2)

1	FLAT WASHER D20*2	0	20PCS
2	SHORT BOLT (M8*50mm)		20PCS
3	ALLEN WRENCH	-	1PC
4	GLASS REST		8PCS

Hardware pack is located in 107891 B2


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM:107891 (B1-B3)

ASSEMBLY INSTRUCTIONS


STEP 1



When assembling parts "C" and "D", make sure not to fully tighten the screws


COASTER

STEP 2



After assembling TOP FRAME "B" with parts "C" completely, also tighten the screws on part "D"

STEP 3




STEP 4





ITEM:107891 (B1-B3)





Note: Dimension tolerance ±5%