


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

108187
ARM CHAIR

ITEM: **108187**

ASSEMBLY INSTRUCTIONS




ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING !


1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME **15 MINUTES**

PARTS IDENTIFICATION

A. FRAME



1PC

B. SEAT CUSHION



1PC

Z HARDWARE PACKAGE

1. ALLEN WRENCH
(M6*57MM-BLACK)



1PC

3. FLAT WASHER
(M6*Ø6MM-BLACK)



3PCS

2. ALLEN BOLT
(M6*30MM-BLACK)




3PCS

NOTE:QUANTITIES SHOWN ARE FOR ONE CHAIRS


ITEM: **108187**
ASSEMBLY INSTRUCTIONS



STEP 1



STEP 2
COMPLETE



Note: Dimension tolerance $\pm 5\%$