

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life



REVISION 0 : 10/05/2023

PAGE 1 OF 3

ITEM: 108221 ASSEMBLY INSTRUCTIONS



COASTERFURNITURE.COM

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.




WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.





HARDWARE IDENTIFICATION


1	ALLEN WRENCH (M5 - BLK)		1PC
2	BOLT (M8 x 70mm - RBW)		8PCS
3	LOCK WASHER (M8 - RBW)	\bigcirc	8PCS
4	FLAT WASHER (M8 - RBW)	\bigcirc	8PCS


PAGE 2 OF 3



ASSEMBLY INSTRUCTIONS

<u>STEP 1</u>







ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life



REVISION 0 : 10/05/2023

PAGE 1 OF 5

ITEM: 108222 ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:


- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.





ITEM: 108222 ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

1	ALLEN WRENCH (M4 - BLK)		1PC
2	SHORT BOLT (M6 x 40mm - RBW)		2PCS
3	LONG BOLT (M6 x 70mm - RBW)		8PCS
4	LOCK WASHER (M6 - RBW)	\bigcirc	10PCS
5	FLAT WASHER (M6 - RBW)	\bigcirc	10PCS
6	FLAT HEAD SCREW (M4 x 25mm- RBW)	(Change and a second se	7PCS

NOTE:

Quantities shown are for one chair.


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

PAGE 3 OF 5




ASSEMBLY INSTRUCTIONS

<u>STEP 1</u>




<u>STEP 2</u>




ASSEMBLY INSTRUCTIONS



STEP 3




<u>STEP 4</u> COMPLETE





PAGE 5 OF 5





ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life



REVISION 0 : 01/04/2024



ITEM: 108223 ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:


- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.




Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

PAGE 2 OF 3

ASSEMBLY INSTRUCTIONS




<u>STEP 1</u>



STEP 2 COMPLETE





Note: Dimension tolerance ±5%