

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

108442
Side Chair

ITEM: **108442**



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS :

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING !

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES


PARTS IDENTIFICATION

A BACKREST



1PC

B UPPER LEG FRAME



1PC

C LOWER LEG FRAME



1PC

D WOOD CLEAT



1PC

E SEAT CUSHION



1PC


HARDWARE IDENTIFICATION

1 ALLEN WRENCH
(M4 x 110MM - BLK)



1PC

2 LONG BOLT
(M6 x 60MM - RBW)



4PCS

3 MEDIUM BOLT
(M6 x 35MM - RBW)




4PCS

4 SHORT BOLT
(M6 x 25MM - RBW)



4PCS

5 HEX HEAD BOLT
(M7 x 50MM - ZB)



1PC

6 LOCK WASHER
(1/4" - BLK)



8PCS

7 FLAT WASHER
(M6 X 13MM - RBW)



4PCS

8 WOOD PLUG
(Ø14.5 X 9MM)



4PCS

NOTE :

Quantities shown are for one chair.


Phillips head screw driver is required in the assembly process; However, manufacturer not provide this item.

ITEM: **108442**




ASSEMBLY INSTRUCTIONS

STEP 1



STEP 2




ITEM: **108442**




ASSEMBLY INSTRUCTIONS

STEP 3



STEP 4




ITEM: **108442**





ASSEMBLY INSTRUCTIONS


STEP 5



STEP 6 **COMPLETE**



ITEM: **108442**



Note: Dimension tolerance $\pm 5\%$