

# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

108461 Dining Table

**REVISION 0: 10/16/2023** 

PAGE 1 OF 4



#### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME



## PARTS IDENTIFICATION

A TOP



1PC

B LEG

4PCS

## HARDWARE IDENTIFICATION

1	ALLEN WRENCH (M4 x 110mm - BLK)		1PC
2	HEX HEAD SCREW (M6.5 x 70mm - RBW)	(a)	8PCS
3	BOLT (M6 x 60mm - RBW)		8PCS
4	LOCK WASHER (1/4" - BLK)		16PCS
5	SMALL FLAT WASHER (M6 x 13mm - RBW)		8PCS
6	BIG FLAT WASHER (1/4" - RBW)		8PCS

#### NOTE:


Phillips head screw driver is required in the assembly process; However, manufacturer not provide this item.

## COASTER\*


### **ASSEMBLY INSTRUCTIONS**

## STEP 1

ATTENTION! PLEASE REMOVE ALL SCREWS AND WOOD BLOCKS BEFORE ASSEMBLE.



## STEP 2




PAGE 3 OF 4

## COASTER

## **ASSEMBLY INSTRUCTIONS**


## STEP 3



# STEP 4 COMPLETE







Note: Dimension tolerance ±5%



# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

108462 Side Chair

**REVISION 0: 10/16/2023** 

PAGE 1 OF 7



#### **ASSEMBLY INSTRUCTIONS**


#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

## **PARTS IDENTIFICATION**

Α	BACKREST	1PC
В	BACK LEG FRAME	1PC
С	FRONT LEG FRAME	1PC
D	RIGHT SIDE RAIL	1PC
E	LEFT SIDE RAIL	1PC
F	RIGHT SIDE STRETCHER	1PC
G	LEFT SIDE STRETCHER	1PC
н	SEAT CUSHION	1PC



#### **ASSEMBLY INSTRUCTIONS**

#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.

## HARDWARE IDENTIFICATION

1	ALLEN WRENCH (M4 x 110MM - BLK)		1PC
2	LONG BOLT (M6 x 50MM - RBW)		4PCS
3	SHORT BOLT (M6 x 30MM - RBW)		4PCS
4	LOCK WASHER (1/4" - BLK)		8PCS
5	FLAT WASHER ( M6 X 13MM - RBW)		8PCS
6	SHORT PAN HEAD SCREW (#8 X 1 1/4")	<del></del>	4PCS
7	LONG PAN HEAD SCREW (#8 X 1 1/2")		4PCS
8	WOOD PLUG (Ø14.5 X 9MM)		4PCS

#### NOTE:


Quantities shown are for one chair.

Phillips head screw driver is required in the assembly process; However, manufacturer not provide this item.


#### **ASSEMBLY INSTRUCTIONS**

## COASTER

## STEP 1




## STEP 2




### **ASSEMBLY INSTRUCTIONS**







## STEP 4




PAGE 5 OF 7


### **ASSEMBLY INSTRUCTIONS**

## STEP 5





## STEP 6




PAGE 6 OF 7


### **ASSEMBLY INSTRUCTIONS**

## COASTER

## STEP 7




# STEP 8 COMPLETE









Note: Dimension tolerance ±5%