

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

108471 Dining Table

REVISION 0: 10/31/2023

PAGE 1 OF 6

COASTER

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME



PARTS IDENTIFICATION

A	ТОР		1PC
В	LEG FRAME	A THE	1PC
С	LEG		2PCS
D	UPPER CROSSBAR		1PC
E	LOWER CROSSBAR		1PC

HARDWARE IDENTIFICATION

1	ALLEN WRENCH (M4 x 110mm - BLK)	1PC
2	BOLT (M6 x 50mm - RBW)	8PCS
3	LOCK WASHER (1/4" - BLK)	8PCS
4	FLAT WASHER (M6 x 13mm - RBW)	8PCS
5	HEX HEAD SCREW (M7 x 50mm - RBW)	1PC
6	DOWEL PIN (M8 X 30MM)	4PCS
7	ADJUSTABLE LEVELER (M6 X 24MM)	4PCS

NOTE:


Phillips head screw driver is required in the assembly process; However, manufacturer not provide this item.

COASTER


ASSEMBLY INSTRUCTIONS

STEP 1

ATTENTION! PLEASE REMOVE ALL SCREWS AND WOOD BLOCKS BEFORE ASSEMBLE.



STEP 2




PAGE 3 OF 6


COASTER

ASSEMBLY INSTRUCTIONS

STEP 3




STEP 4




COASTER

ASSEMBLY INSTRUCTIONS

STEP 5



STEP 6




PAGE 5 OF 6

COASTER

ASSEMBLY INSTRUCTIONS

STEP 7




STEP 8 COMPLETE



PAGE 6 OF 6





Note: Dimension tolerance ±5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

108472 Side Chair

REVISION 0 : 10/11/2023 REVISION 1 : 11/12/2025



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A	BACK FRAME	1PC
В	FRONT LEG FRAME	1PC
С	LEFT SIDE RAIL	1PC
D	RIGHT SIDE RAIL	1PC
E	LEFT STRETCHER	1PC
F	RIGHT STRETCHER	1PC
G	SUPPORT BAR	2PCS
Н	SEAT CUSHION	1PC

NOTE:

Quantities shown are for one chair.

Phillips head screw driver is required in the assembly process; However, manufacturer not provide this item.



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

1	ALLEN WRENCH (M5 x 100MM - BLK)		1PC
2	BOLT (M8 x 50MM - BLK)		4PCS
3	LOCK WASHER (5/16" - BLK)		4PCS
4	LONG PAN HEAD SCREW (#8 x 1 1/2" - BLK)	←шшшш (]	4PCS
5	SHORT PAN HEAD SCREW (#8 x 1 1/4" - BLK)	√mmm()	4PCS
6	L BRACKET (ZY 447 - BLK)		3PCS
7	FLAT HEAD SCREW (M3.5 x 16MM- RBW)	4000(P)	6PCS

NOTE:


Quantities shown are for one chair.

Phillips head screw driver is required in the assembly process; However, manufacturer not provide this item.


COASTER

ASSEMBLY INSTRUCTIONS

STEP 1




STEP 2




COASTER

ASSEMBLY INSTRUCTIONS

STEP 3



STEP 4




PAGE 5 OF 6


COASTER


ASSEMBLY INSTRUCTIONS

STEP 5




STEP 6 COMPLETE









Note: Dimension tolerance ±5%