

# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

# 108540 (B1&B2) *Dining Table*

REVISION 0: 02/26/2025

PAGE 1 OF 5

## ITEM: 108540(B1&B2) ASSEMBLY INSTRUCTIONS



#### **ASSEMBLY TIPS:**


- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.





#### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.








PAGE 4 OF 5


# ITEM: 108540(B1&B2) ASSEMBLY INSTRUCTIONS




## STEP 6



## STEP 7 COMPLETE





Note: Dimension tolerance ±5%



# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life



REVISION 0: 02/26/2025

PAGE 1 OF 4

## ITEM: 108542 ASSEMBLY INSTRUCTIONS



#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.





Α	BACK FRAME		1PC	E LEFT SIDE STRETCHER
В	SEAT CUSHION WITH FRAME		1PC	F RIGHT SIDE STRETCHER - 1PC
С	LEFT FRONT LEG	e · T	1PC	G MIDDLE STRETCHER $\longleftrightarrow$ 1PC
D	RIGHT FRONT LEG	- B	1PC	

## HARDWARE IDENTIFICATION

1	LONG BOLT (Ø1/4" x 3" - RBW)	(0)=)))))))))))))))))))))))))))))))))))	4PCS	5	FLAT WASHER (Ø1/4" - RBW)	0	10PCS
2	MEDIUM BOLT (Ø1/4" x 2" - RBW)		4PCS	6	ALLEN WRENCH (4MM - RBW)		1PC
3	SHORT BOLT (Ø1/4" x 1-1/2" - RBW)		2PCS	7	PAN HEAD SCREW (#8MM x 1-1/2" - RBW)	()	6PCS
4	LOCK WASHER (Ø1/4" - RBW)	$\bigcirc$	10PCS				


#### NOTE:

Quantities shown are for one chair. Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

# ITEM: 108542 ASSEMBLY INSTRUCTIONS




STEP 1




# COMPLETE 00000000000 PAGE 4 OF 4

## ITEM:108542 **ASSEMBLY INSTRUCTIONS STEP 3**











# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life



REVISION 0: 02/26/2025

PAGE 1 OF 3

## ITEM: 108543 ASSEMBLY INSTRUCTIONS



#### **ASSEMBLY TIPS:**


- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

# $\triangle$

#### WARNING!


1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.

2. This product is for home use only and not intended for commercial establishments.



# ITEM:108543 COASTER **ASSEMBLY INSTRUCTIONS** FINE FURNITURE STEP 1 3 B 2 1 4 Â B STEP 2 **4** 1 2 B C 3 V **STEP 3** COMPLETE





Note: Dimension tolerance ±5%