

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

108541 (B1&B2) *Dining Table*

REVISION 0: 02/26/2025

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

B1 (BOX 1)

A TOP

1PC

D CROSSBAR

1PC

B LEAF



2PCS

E MIDDLE CROSSBAR

2PCS

C APRON



2PCS

B2 (BOX 2)

F LEG FRAME



2PCS

HARDWARE IDENTIFICATION

Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 108541(B1)

1	SHORT BOLT
	(Ø5/16" x 1-1/2" - RBW)



12PCS

6 HEX NUT (Ø5/16" - RBW)



4PCS

2 LONG BOLT (Ø5/16" x 2" - RBW)



4PCS

7 HALF ROUND NUT (Ø5/16" - RBW)



4PCS

3 THREADED BOLT (Ø5/16" x 3" - RBW)



4PCS

8 ALLEN WRENCH (4MM - RBW



1PC

4 LOCK WASHER (Ø5/16" - RBW)




16PCS

9 WRENCH (RBW)



1PC

5 FLAT WASHER





16PCS


COASTERFURNITURE.COM

PAGE 2 OF 5


ASSEMBLY INSTRUCTIONS

STEP 1






STEP 2




STEP 3




ASSEMBLY INSTRUCTIONS






STEP 5




PAGE 4 OF 5

ITEM: 108541(B1&B2) ASSEMBLY INSTRUCTIONS STEP 6






STEP 7 COMPLETE







Note: Dimension tolerance ±5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

108545NAT Sideboard

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.






15 MINUTES

PARTS IDENTIFICATION


A	SIDEBOARD		1PC			
В	LEG FRAME		2PCS			
С	CENTER SUPPORT LEG WITH LEVELER		1PC			
HARDWARE IDENTIFICATION						
1	BOLT (Ø5/16" x 1-1/2" - RBW)		6PCS			
2	LOCK WASHER (Ø5/16" - RBW)		6PCS			
3	FLAT WASHER (Ø5/16" - RBW)		6PCS			
4	ALLEN WRENCH (4MM - RBW)		1PC			

ITEM: 108545NAT ASSEMBLY INSTRUCTIONS STEP 1





STEP 2




PAGE 3 OF 6

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS


STEP 3





NOTE: Please only open one door of the sideboard when using it.

STEP 4 COMPLETE





PAGE 4 OF 6


COASTERFURNITURE.COM




OPTIONAL ADJUSTABLE SHELF









NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.



ANTI-TIPPING INSTALLATION INSTRUCTIONS FURNITURE TIPPING RESTRAINT

WARNING

Injury may result from tipping furniture.


This restraint may protect against tipping furniture.

Do not allow children to climb on furniture.

This restraint is not a substitute for proper adult supervision.

Failure to detach this restraint before moving the furniture may result in injury and damage.


- 1. Attach one of the mounting brackets securely to the back edge of the unit, using the short screw.
- 2. Determine where the unit is to be placed, and mark the location on the wall for the other mounting bracket. The bracket on the wall needs to be approximately 2" below the bracket mounted to the edge of the unit.
- 3. Drill a hole in the wall. Insert the plastic wall anchor into the hole and if necessary, use a small block of wood and hammer to tap it in so that it's flush with the wall.
- 4. Attach the bracket over the plastic wall anchor using the long screw.
- 5. Place the unit against the wall, both brackets need to be facing each other.
- 6. Lace an end of the restraint strap through the hole in each bracket. Bring both ends together and rotate the thumb nut onto the threaded end until tight.
- 7. Ensure that the restraint strap is securely laced and locked.











Note: Dimension tolerance ±5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

108546NAT Side Chair

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.





15 MINUTES

PARTS IDENTIFICATION

A	SEAT AND BACK		1PC
В	LEFT LEG FRAME		1PC
С	RIGHT LEG FRAME		1PC
D	MIDDLE STRETCHER		1PC
	HARDWARE	IDENTIFICATION	
1	ROLT	(Ammuno)	ADC 9

1	BOLT (Ø1/4" x 1-1/2" - RBW)		4PCS
2	LOCK WASHER (Ø1/4" - RBW)		4PCS
3	FLAT WASHER (Ø1/4" - RBW)		4PCS
4	ALLEN WRENCH (4MM - RBW)		1PC
5	PAN HEAD SCREW (#8MM x 1" - RBW)	$\{\}$	2PCS

NOTE:


Quantities shown are for one chair.

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ASSEMBLY INSTRUCTIONS



STEP 1




STEP 2 COMPLETE









Note: Dimension tolerance ±5%