



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

108541 (B1&B2)
Dining Table

ITEM: 108541(B1&B2)

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

B1 (BOX 1)

A TOP



1PC

B LEAF



2PCS

C APRON




2PCS

D CROSSBAR



1PC


E MIDDLE CROSSBAR



2PCS

B2 (BOX 2)

F LEG FRAME



2PCS

HARDWARE IDENTIFICATION

Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 108541(B1)

1 SHORT BOLT
(Ø5/16" x 1-1/2" - RBW)



12PCS

2 LONG BOLT
(Ø5/16" x 2" - RBW)



4PCS

3 THREADED BOLT
(Ø5/16" x 3" - RBW)



4PCS

4 LOCK WASHER
(Ø5/16" - RBW)



16PCS

5 FLAT WASHER
(Ø5/16" - RBW)



16PCS

6 HEX NUT
(Ø5/16" - RBW)



4PCS

7 HALF ROUND NUT
(Ø5/16" - RBW)



4PCS

8 ALLEN WRENCH
(4MM - RBW)



1PC

9 WRENCH
(RBW)




1PC

ITEM: **108541(B1&B2)**


ASSEMBLY INSTRUCTIONS




STEP 1



STEP 2



STEP 3




ITEM: **108541(B1&B2)**


ASSEMBLY INSTRUCTIONS



STEP 4




STEP 5




ITEM: **108541(B1&B2)**

ASSEMBLY INSTRUCTIONS


STEP 6



STEP 7 COMPLETE



ITEM: **108541(B1&B2)**



Note: Dimension tolerance $\pm 5\%$



ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

108546BLK
Side Chair

ITEM: 108546BLK

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!





1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.








ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

A	SEAT AND BACK		1PC
B	LEFT LEG FRAME		1PC
C	RIGHT LEG FRAME		1PC
D	MIDDLE STRETCHER		1PC

HARDWARE IDENTIFICATION

1	BOLT (Ø1/4" x 1-1/2" - RBW)		4PCS
2	LOCK WASHER (Ø1/4" - RBW)		4PCS
3	FLAT WASHER (Ø1/4" - RBW)		4PCS
4	ALLEN WRENCH (4MM - RBW)		1PC
5	PAN HEAD SCREW (#8MM x 1" - RBW)		2PCS

NOTE:


Quantities shown are for one chair.

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


ITEM: **108546BLK**
ASSEMBLY INSTRUCTIONS




STEP 1



STEP 2
COMPLETE



ITEM: **108546BLK**



Note: Dimension tolerance $\pm 5\%$