

# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

108551 Dining Table

REVISION 0: 07/08/2024

PAGE 1 OF 3

#### **ASSEMBLY INSTRUCTIONS**



#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME



## PARTS IDENTIFICATION

A TOP



1PC

B LEG



4PCS

### HARDWARE IDENTIFICATION


1	ALLEN WRENCH (12.8MM - RBW)	1PC
2	BOLT (M6 x 90MM - SR)	8PCS
3	HEX BOLT SCREW (M6.5 x 70MM - SR)	8PCS
4	LOCK WASHER (1/4" - BLK)	16PCS
5	SMALL FLAT WASHER (M6 X 13MM - RBW)	8PCS
6	BIG FLAT WASHER (5/16" - RBW)	8PCS

### **ASSEMBLY INSTRUCTIONS**




## STEP 1


ATTENTION! PLEASE REMOVE ALL SCREWS & WOOD BLOCKS BEFORE ASSEMBLE.




## STEP 2




# STEP 3 COMPLETE









Note: Dimension tolerance ±5%



# ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

108552 Side Chair

REVISION 0: 07/08/2024

PAGE 1 OF 7

#### **ASSEMBLY INSTRUCTIONS**



#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



#### **ATTENTION / WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

20 MINUTES

## PARTS IDENTIFICATION

Α	UPPER LEG FRAME	O Parking.	1PC
В	LOWER LEG FRAME		1PC
С	LONG WOOD CLEAT		1PC
D	SHORT WOOD CLEAT		1PC
E	UPPER STRETCHER	5	1PC
F	LOWER STRETCHER	R	1PC
G	SEAT CUSHION		1PC
Н	BACKREST		1PC

#### NOTE:

Quantities shown are for one chair.

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

#### **ASSEMBLY INSTRUCTIONS**



#### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



#### ATTENTION / WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.

## HARDWARE IDENTIFICATION

1	ALLEN WRENCH (M4 x 110MM - BLK)	1PC
2	BOLT 1 (M6 x 25MM - RBW)	2PCS
3	BOLT 2 (M6 x 35MM - RBW)	8PCS
4	BOLT 3 (M6 x 50MM - RBW)	4PCS
5	BOLT 4 (M6 x 60MM - RBW)	4PCS
6	LOCK WASHER (1/4" - BLK)	18PCS
7	FLAT WASHER (M6 x 13MM - RBW)	18PCS
8	HEX BOLT (M7 x 20MM - RBW)	1PC
9	WOOD PLUG (Ø14.5 x 9MM)	2PCS


#### NOTE:

Phillips head screw driver is required in the assembly process; However, manufacturer not provide this item. Quantities shown are for one chair.


## **ASSEMBLY INSTRUCTIONS**



# STEP 1



# STEP 2




PAGE 4 OF 7


## **ASSEMBLY INSTRUCTIONS**



## STEP 3




# STEP 4




## **ASSEMBLY INSTRUCTIONS**

# COASTER

# STEP 5




## STEP 6



## **ASSEMBLY INSTRUCTIONS**


# COASTER

# STEP 7




# STEP 8 COMPLETE









Note: Dimension tolerance ±5%