

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life



REVISION 0: 07/08/2024

PAGE 1 OF 3

ITEM : 108551

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS :

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



Α

В

WARNING !

- 1. Don't attempt to repair or modify parts that are broken or defective.Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.






PARTS IDENTIFICATION

1PC

TOP



LEG



4PCS

HARDWARE IDENTIFICATION


1	ALLEN WRENCH (12.8MM - RBW)		1PC
2	BOLT (M6 x 90MM - SR)		8PCS
3	HEX BOLT SCREW (M6.5 x 70MM - SR)		8PCS
4	LOCK WASHER (1/4" - BLK)		16PCS
5	SMALL FLAT WASHER (M6 X 13MM - RBW)	\bigcirc	8PCS
6	BIG FLAT WASHER (5/16" - RBW)	\bigcirc	8PCS






STEP 1

ATTENTION! PLEASE REMOVE ALL SCREWS & WOOD BLOCKS BEFORE ASSEMBLE.




STEP 2



STEP 3 COMPLETE









ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life



REVISION 0: 07/08/2024

PAGE 1 OF 7



ASSEMBLY TIPS :

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



ATTENTION / WARNING !

- 1. Don't attempt to repair or modify parts that are broken or defective.Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 20 MINUTES

 PARTS IDENTIFICATION

Α	UPPER LEG FRAME	C A WAL	1PC
В	LOWER LEG FRAME		1PC
С	LONG WOOD CLEAT		1PC
D	SHORT WOOD CLEAT		1PC
Е	UPPER STRETCHER	<u> </u>	1PC
F	LOWER STRETCHER		1PC
G	SEAT CUSHION		1PC
н	BACKREST		1PC

NOTE:

Quantities shown are for one chair.

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

PAGE 2 OF 7



ASSEMBLY TIPS :

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instruction in the same sequence as numbered to assure fast & easy assembly.



ATTENTION / WARNING !

- 1. Don't attempt to repair or modify parts that are broken or defective.Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION


1	ALLEN WRENCH (M4 x 110MM - BLK)		1PC
2	BOLT 1 (M6 x 25MM - RBW)		2PCS
3	BOLT 2 (M6 x 35MM - RBW)		8PCS
4	BOLT 3 (M6 x 50MM - RBW)		4PCS
5	BOLT 4 (M6 x 60MM - RBW)		4PCS
6	LOCK WASHER (1/4" - BLK)		18PCS
7	FLAT WASHER (M6 x 13MM - RBW)	\bigcirc	18PCS
8	HEX BOLT (M7 x 20MM - RBW)		1PC
9	WOOD PLUG (Ø14.5 x 9MM)	\bigcirc	2PCS

NOTE :


Phillips head screw driver is required in the assembly process; However, manufacturer not provide this item. Quantities shown are for one chair.



STEP 1




STEP 2






STEP 3






STEP 5




STEP 6







STEP 7



STEP 8 COMPLETE







Note : Dimension tolerance ±5%