

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

108571
Dining Table

ITEM: **108571**

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION

A TOP




1PC

B APRON



2PCS

C LEG FRAME



2PCS

D CROSSBAR



1PC

HARDWARE IDENTIFICATION

1 ALLEN WRENCH
(M4 x 100mm - BLK)



1PC

2 BOLT
(M6 x 50mm - RBW)



10PCS

3 HALF ROUND NUT
(M6 - BLK)



8PCS

4 LOCK WASHER
(M6 - RBW)



2PCS

5 PLASTIC DOWEL
(M8 x 30mm - BLK)



4PCS

6 FLAT HEAD SCREW
(M4 x 38mm - RBW)



14PCS

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **108571**




ASSEMBLY INSTRUCTIONS


STEP 1



STEP 2



STEP 3




ITEM: **108571**




ASSEMBLY INSTRUCTIONS

STEP 4




STEP 5

COMPLETE



ITEM: **108571**



Note: Dimension tolerance $\pm 5\%$

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

108572
Side Chair

ITEM: **108572**



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!





1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.










ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A	BACK FRAME		1PC
B	SEAT FRAME		1PC
C	SEAT CUSHION		1PC
D	FRONT LEG		2PCS

HARDWARE IDENTIFICATION

1	ALLEN WRENCH (M4 x 100mm - BLK)		1PC
2	SHORT BOLT (M6 x 40mm - RBW)		2PCS
3	MEDIUM BOLT (M6 x 60mm - RBW)		4PCS
4	LONG BOLT (M6 x 70mm - RBW)		4PCS
5	LOCK WASHER (M6 - RBW)		10PCS
6	FLAT WASHER (M6 - RBW)		10PCS
7	FLAT HEAD SCREW (M4 x 25mm - RBW)		5PCS

NOTE:

Quantities shown are for one chair.


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: **108572**




ASSEMBLY INSTRUCTIONS


STEP 1




STEP 2




STEP 3



STEP 4 **COMPLETE**



ITEM: **108572**



Note: Dimension tolerance $\pm 5\%$