

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

109181 *Dining Table*

REVISION 0: 03/25/2024 REVISION 1: 11/21/2024

PAGE 1 OF 3

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION

A TOP

BF LEG WITH LABEL "L"

2PCS

CF LEG WITH LABEL "R"

2PCS


HARDWARE IDENTIFICATION

1	ALLEN WRENCH (M4 x 100mm - BLK)	1PC
2	SHORT BOLT (M6 x 40mm - RBW)	8PCS
3	LONG BOLT (M6 x 50mm - RBW)	4PCS
4	HALF ROUND NUT (M6 - BLK)	4PCS
5	LOCK WASHER (M6 - RBW)	8PCS
6	FLAT WASHER (M6 - RBW)	8PCS
7	PLASTIC DOWEL (M8 x 30mm - BLK)	8PCS


ASSEMBLY INSTRUCTIONS




STEP 1




STEP 2



STEP 3




STEP 4 COMPLETE









Note: Dimension tolerance ±5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

REVISION 0: 03/25/2024

109182 Side Chair

PAGE 1 OF 3 COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

Α	BACK FRAME	1PC
В	SEAT FRAME	1PC
С	SEAT CUSHION	1PC
D	FRONT LEG	2PCS

HARDWARE IDENTIFICATION

1	ALLEN WRENCH (M4 x 100mm - BLK)		1PC
2	SHORT BOLT (M6 x 40mm - RBW)		2PCS
3	MEDIUM BOLT (M6 x 60mm - RBW)		4PCS
4	LONG BOLT (M6 x 70mm - RBW)		4PCS
5	LOCK WASHER (M6 - RBW)		10PCS
6	FLAT WASHER (M6 - RBW)		10PCS
7	FLAT HEAD SCREW (M4 x 25mm- RBW)	D	5PCS

NOTE:


Quantities shown are for one chair.

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


COASTER

ASSEMBLY INSTRUCTIONS


STEP 1




STEP 2



STEP 3




STEP 4



PAGE 3 OF 3





Note: Dimension tolerance ±5%