

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life


109381 (B1&B2) *Dining Table*

REVISION 0: 01/08/2025

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS





- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION

B1 (BOX 1)

а ТОР



1PC

B LEAF

1PC

B2 (BOX 2)

C LEFT BASE WITH "L" LABEL



1PC

D RIGHT BASE WITH "R" LABEL



1PC

E CROSSBAR



1PC

COVER CAP

2PCS

HARDWARE IDENTIFICATION

Z-B2 (BOX 2) - HARDWARE PACK IS LOCATED IN 109381 (B2)

BOLT (ø5/16" x 45MM- RBW)



12PCS

FLAT WASHER (Ø5/16" - RBW)



12PCS

2 LOCK WASHER (Ø5/16" - RBW)



12PCS

4 ALLEN WRENCH (M4 x 60MM -RBW)

1PC


NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ASSEMBLY INSTRUCTIONS

COASTER

STEP 1




*BOTTOM VIEW PAGE 3 OF 5 COASTERFURNITURE.COM


ASSEMBLY INSTRUCTIONS



STEP 3



STEP 4




PAGE 4 OF 5


COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS STEP 5






STEP 6 COMPLETE



凉





Note: Dimension tolerance ±5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

109382 Side Chair

REVISION 0: 01/08/2025

PAGE 1 OF 4

COASTERFURNITURE.COM

ITEM: 109382

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION

A BACK FRAME

1PC

B SEAT CUSHION WITH FRAME

1PC

C LEFT FRONT LEG

1PC

D RIGHT FRONT LEG

1PC

E LEFT SIDE STRETCHER

1PC

F RIGHT SIDE STRETCHER

1PC

HARDWARE IDENTIFICATION


1	LONG BOLT (Φ1/4 " x 75mm - RBW)	4PCS	5	FLAT WASHER (Φ1/4"- RBW)		10PCS
2	MEDIUM BOLT (Φ1/4" x 60mm - RBW)	4PCS	6	ALLEN WRENCH (M4 x60MM - RBW)		1PC
3	SHORT BOLT (Ф1/4 " x 45 mm - RBW)	2PCS	7	PAN HEAD SCREW (Ø4 x 40MM - RBW)	(111111111111111111111111111111111111	4PCS
4	LOCK WASHER (Φ1/4" - RBW)	10PCS				

NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: 109382 ASSEMBLY INSTRUCTIONS STEP 1





STEP 2




ITEM: **109382**


ASSEMBLY INSTRUCTIONS

STEP 3






STEP 4 COMPLETE





ITEM: **109382**





Note: Dimension tolerance ±5%