

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



109453
Dining bench

ITEM: 109453 (B1-B2)



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

B1 (BOX 1)


A SEAT CUSHION



1PC

B2 (BOX 2)

B LEG FRAME



2PCS

NOTE:

Quantities shown are for on chair

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.






WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION

Z-B2 (BOX 2) - HARDWARE PACK IS LOCATED IN 109453 (B2)

1	ALLEN WRENCH 8mm		1PC
2	SHORT BOLT (M8*40mm)		6PCS
3	Flat washer (Dia10mm)		6PCS

Hardware pack is located in 109453 B2


NOTE:

Quantities shown are for on chair


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ASSEMBLY INSTRUCTIONS

STEP 1




STEP 2



THE LONG BECHN FIXED ADJUST FEETS





Note : Dimension tolerance $\pm 5\%$