

*ASSEMBLY INSTRUCTIONS*  
*COASTER FINE FURNITURE*



*Fine Furniture for every stage of life*

**110291(B1&B2)**  
***Dining Table***

# ITEM: 110291(B1&B2)

## ASSEMBLY INSTRUCTIONS



### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

## PARTS IDENTIFICATION

### B1 (BOX 1)

AN	TOP		1PC
BN	LEAF		1PC
CN	LOWER CROSSBAR		1PC
DN	UPPER CROSSBAR		1PC

### B2 (BOX 2)

EN	LEG FRAME		2PCS
----	-----------	--	------

## HARDWARE IDENTIFICATION

### Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 110291(B1)


1	<b>BOLT</b> (Ø5/16 x 13 x 45mm - RBW)		16PCS
2	<b>LOCK WASHER</b> (Ø5/16 x 10 x 1.1mm - RBW)		16PCS
3	<b>FLAT WASHER</b> (Ø5/16 x 22 x 2mm - RBW)		16PCS
4	<b>ALLEN WRENCH</b> (4 x 60mm - RBW)		1PC

# ITEM: 110291(B1&B2)




## ASSEMBLY INSTRUCTIONS

### STEP 1



**BOTTOM VIEW**

### STEP 2




ITEM: **110291(B1&B2)**


## ASSEMBLY INSTRUCTIONS



### STEP 3



### STEP 4




ITEM: **110291(B1&B2)**



## ASSEMBLY INSTRUCTIONS




### STEP 5



### STEP 6 COMPLETE



ITEM: **110291(B1&B2)**



**Note: Dimension tolerance  $\pm 5\%$**



# *ASSEMBLY INSTRUCTIONS*

## *COASTER FINE FURNITURE*



*Fine Furniture for every stage of life*

**110292**  
**Side Chair**

# ITEM:110292

## ASSEMBLY INSTRUCTIONS

### ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



### WARNING!



1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.









ASSEMBLY TIME

15 MINUTES

## PARTS IDENTIFICATION

AN	BACK FRAME		1PC
BN	SEAT CUSHION WITH FRAME		1PC
CN	FRONT LEG		2PCS

## HARDWARE IDENTIFICATION

1	<b>LONG BOLT</b> (Ø1/4 x 13 x 75mm - RBW)		4PCS
2	<b>MEDIUM BOLT</b> (Ø1/4 x 13 x 63mm - RBW)		4PCS
3	<b>SHORT BOLT</b> (Ø1/4 x 13 x 38mm - RBW)		2PCS
4	<b>LOCK WASHER</b> (Ø1/4 x 10 x 1.1mm - RBW)		10PCS
5	<b>FLAT WASHER</b> (Ø1/4 x 22 x 2mm - RBW)		10PCS
6	<b>ALLEN WRENCH</b> (4 x 60mm - RBW)		1PC

### NOTE:

Quantities shown are for one chair.


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.




ITEM: **110292**

## ASSEMBLY INSTRUCTIONS

### STEP 1




### STEP 2




ITEM: **110292**

## ASSEMBLY INSTRUCTIONS

### STEP 3




### STEP 4 COMPLETE



ITEM: **110292**

**COASTER**  
FINE FURNITURE



Note: Dimension tolerance  $\pm 5\%$