

ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

105143
Dining Chair

ITEM: **105143**

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instruction in the same sequence as numbered to assure fast and easy assembly.



WARNING !

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.




ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

AD

BACK FRAME



1PC

BD


SEAT CUSHION
WITH FRAME



1PC

CD

FRONT LEG



2PCS

HARDWARE IDENTIFICATION

1


LONG BOLT
(M8 x 60mm - BLK)



4PCS

2

SHORT BOLT
(M8 x 50mm - BLK)



7PCS

3

LOCK WASHER
(M8 - BLK)



11PCS

4

FLAT WASHER
(M8 - BLK)



11PCS


5

ALLEN WRENCH
(M5 - BLK)




1PC

ITEM: **105143**
ASSEMBLY INSTRUCTIONS
STEP 1



STEP 2




ITEM: **105143**

ASSEMBLY INSTRUCTIONS


STEP 3

COASTER
FINE FURNITURE




STEP 4

COMPLETE



ITEM: **105143**



Note : Dimension tolerance \pm 5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

110331 Dining Table

REVISION 0: 04/13/2017
REVISION 1: 09/04/2018
REVISION 2: 04/24/2019
REVISION 3: 07/24/2019
REVISION 4: 09/27/2019

ITEM: 110331



ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!





1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

20 MINUTES

PARTS IDENTIFICATION

A	TOP		1PC
B	LEG FRAME		2PCS
C	CROSSBAR		1PC
D	WOOD CLEAT		2PCS

ITEM: 110331



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:










1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

HARDWARE IDENTIFICATION


1	MEDIUM BOLT (M8 x 50mm - BLK)		16PCS
2	LONG BOLT (M6 x 100mm - BLK)		4PCS
3	SHORT BOLT (M6 x 45mm - BLK)		2PCS
4	BIG LOCK WASHER (Ø13 x Ø8 x 2mm - BLK)		16PCS
5	BIG FLAT WASHER (Ø18 x Ø8 x 1mm - BLK)		16PCS
6	SMALL LOCK WASHER (Ø13 x Ø6 x 1mm - BLK)		6PCS
7	SMALL FLAT WASHER (Ø16 x Ø6.5 x 1mm - BLK)		6PCS
8	SMALL ALLEN WRENCH (4MM - BLK)		1PC
9	BIG ALLEN WRENCH (5MM - BLK)		1PC

ITEM: 110331


ASSEMBLY INSTRUCTIONS



STEP 1




STEP 2




ITEM: **110331**

ASSEMBLY INSTRUCTIONS



STEP 3




STEP 4



STEP 5 COMPLETE



ITEM: 110331



Note: Dimension tolerance $\pm 5\%$

S