


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

105076(B1-B2) <u>Side Chair</u>


PAGE 1 OF 3

ITEM: 105076(B1-B2)

ASSEMBLY INSTRUCTIONS



1. Remove hardware from box and sort by size.



3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION

B1(BOX 1)

SEAT AND BACK



B2(BOX 2)

BASE



1PC

Z

HARDWARE IDENTIFICATION

BOLTS M6*25 1



4PCS

FLAT WASHER Ø6*16



4PCS

ALLEN WRENCH 4MM



NOTE:

Quantities shown are for one chair.

Hardware pack is located in 105076B2

PAGE 2 OF 3


COASTERFURNITURE.COM


ITEM: 105076(B1-B2)

ASSEMBLY INSTRUCTIONS




STEP1







ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

REVISION 0: 04/20/2020

115091(B1-B3) *Dining Table*

PAGE 1 OF 3

COASTERFURNITURE.COM

ITEM: **115091(B1-B3)**

ASSEMBLY INSTRUCTIONS



1. Remove hardware from box and sort by size.



3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!


Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME


10 MINUTES

PARTS IDENTIFICATION



Z HARDWARE IDENTIFICATION

B3(BOX 3)-HARDWARE PACK IS LOCATED IN 115091(B3)




ITEM: **115091(B1-B3)**


ASSEMBLY INSTRUCTIONS




STEP1




STEP2



STEP3





NOTE :DIMENSION TOLERANCE ±5% COASTERFURNITURE.COM