


ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

115200CHRB1
DINING TABLE BASE

REVISION 0 : 08/19/2026

ITEM:115200CHRB1

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.




WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME 20 MINUTES


PARTS IDENTIFICATION

A GLASS
GLASS SOLD SEPARATELY




1PC

B ROUND FRAME



2PCS

C LEG



4PCS

ITEM:115200CHRB1

ASSEMBLY INSTRUCTIONS



Z

HARDWARE IDENTIFICATION

1 BOLT
(1/4" x 15mm) 16PCS



2 BOLT
(1/4" x 28mm) 8PCS



3 SUCTION CUP 4PCS




4 LEVELER
(1/4" x 12mm) 4PCS




5 ALLEN WRENCH
(4mm) 1PC



STEP 1



STEP 2




ITEM:115200CHRB1



ASSEMBLY INSTRUCTIONS


STEP 3

GLASS(PART#A) SOLD SEPARATELY



STEP 4 COMPLETE


GLASS(PART#A) SOLD SEPARATELY



ITEM:115200CHRB1 ASSEMBLY INSTRUCTIONS



GLASS(PART#A) SOLD SEPARATELY



Note : Dimension tolerance $\pm 5\%$