


ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

115210CHRB1
DINING TABLE BASE

REVISION 0 : 08/19/2026

PAGE 1 OF 5

COASTERFURNITURE.COM

ITEM: **115210CHRB1**



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.




WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME **15 MINUTES**


PARTS IDENTIFICATION

A GLASS
GLASS SOLD SEPARATELY




1PC

B LARGE FRAME




1PC

C SIDE FRAME



2PCS

D FRAME SUPPORT



2PCS

ITEM:115210CHRB1



ASSEMBLY INSTRUCTIONS

Z

HARDWARE IDENTIFICATION

1 BOLT
(1/4" x 15mm)



10PCS

4 WASHER
(ϕ 19mm)



2PCS

2 SUCTION CUP



5PCS

5 ALLEN WRENCH
(4mm)




1PC

3 CAP
(25 x 25mm)




4PCS

STEP 1




STEP 2



ITEM: **115210CHRB1**
ASSEMBLY INSTRUCTIONS
STEP 3




GLASS(PART#A)SOLD SEPARATELY



STEP 4
COMPLETE


GLASS(PART#A)SOLD SEPARATELY



ITEM:115210CHRB1 ASSEMBLY INSTRUCTIONS



GLASS(PART#A)SOLD SEPARATELY



Note : Dimension tolerance $\pm 5\%$