


ASSEMBLY INSTRUCTIONS
COASTER FINE FURNITURE



Fine Furniture for every stage of life

115240BLKB1
DINING TABLE BASE

REVISION 0 : 08/19/2026

PAGE 1 OF 7

COASTERFURNITURE.COM

ITEM:115240BLKB1

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.




WARNING!

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

ASSEMBLY TIME 25 MINUTES


PARTS IDENTIFICATION

A GLASS
GLASS SOLD SEPARATELY




1PC

B TOP FRAME




1PC

C BOTTOM FRAME



1PC

D LEG



4PCS


ITEM:115240BLKB1

ASSEMBLY INSTRUCTIONS

PARTS IDENTIFICATION



E LARGE FRAME



1PC

F SIDE FRAME 1



1PC

G SIDE FRAME 2



1PC

Z

HARDWARE IDENTIFICATION

1 SHORT BOLT
(1/4" x 12mm) 12PCS



2 BOLT
(1/4" x 25mm) 4PCS



3 LONG BOLT
(1/4" x 50mm) 4PCS



4 LEVLER
(1/4" x 12mm) 4PCS



5 SUCTION CUP 4PCS




6 WASHER
(ø19mm) 4PCS




7 ALLEN WRENCH
(4mm) 1PC




ITEM: **115240BLKB1**
ASSEMBLY INSTRUCTIONS
STEP 1




STEP 2




ITEM: **115240BLKB1**
ASSEMBLY INSTRUCTIONS
STEP 3



STEP 4




ITEM:115240BLKB1
ASSEMBLY INSTRUCTIONS
STEP 5




STEP 6

GLASS(PART#A)SOLD SEPARATELY




COMPLETE



ITEM: **115240BLKB1**
ASSEMBLY INSTRUCTIONS



GLASS(PART#A)SOLD SEPARATELY



Note : Dimension tolerance $\pm 5\%$