

## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

# 115271(B1&B2) **Dining Table**

REVISION 0: 02/18/2022

PAGE 1 OF 4

COASTERFURNITURE.COM

## ITEM: 115271(B1&B2)

### **ASSEMBLY INSTRUCTIONS**

### **ASSEMBLY TIPS:**

- Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.




ASSEMBLY TIME

10 MINUTES

### PARTS IDENTIFICATION

**B1 (BOX 1)** 

A TOP



1PC

**B** MOUNTING PLATE

2PCS

**B2 (BOX 2)** 

C LEG FRAME



2PCS

### HARDWARE IDENTIFICATION

### Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 115271 (B1)

1	BOLT WITH BIG WASHER (M6 x 45mm - BLK)	16PCS
2	BOLT WITH SMALL WASHER (M6 x 50mm - BLK)	10PCS
3	FLAT HEAD SCREW (M5 x 32mm - BLK)	4PCS
4	ALLEN WRENCH	1PC


#### NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.


# ITEM: 115271(B1&B2) ASSEMBLY INSTRUCTIONS



## STEP 1




### STEP 2




# ITEM: 115271(B1&B2) ASSEMBLY INSTRUCTIONS



### STEP 3




## STEP 4 **COMPLETE**





## ITEM: 115271(B1&B2)





Note: Dimension tolerance ±5%



## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

## 115272 Dining Side Chair

REVISION 0: 02/18/2022

PAGE 1 OF 3

COASTERFURNITURE.COM

### ITEM: 115272

### **ASSEMBLY INSTRUCTIONS**

### **ASSEMBLY TIPS:**

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

10 MINUTES

### **PARTS IDENTIFICATION**

A BACK FRAME 1PC

B SEAT CUSHION WITH FRAME 1PC

C FRONT LEG 2PCS

### HARDWARE IDENTIFICATION

1 LONG BOLT WITH WASHER
(M6 x 80mm - BLK)

2 MEDIUM BOLT WITH WASHER
(M6 x 60mm - BLK)

3 SHORT BOLT WITH WASHER
(M6 x 45mm - BLK)

4 ALLEN WRENCH
(M4 - GD)

#### NOTE:

Quantities shown are for one chair.


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

## ITEM: 115272


### **ASSEMBLY INSTRUCTIONS**




### STEP 1



### STEP 2



# STEP 3 COMPLETE






PAGE 3 OF 3

COASTERFURNITURE.COM

## ITEM: 115272





Note: Dimension tolerance ±5%