

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

115172

SIDE CHAIR

REVISION 0: 06/30/2024 REVISION 1: 07/28/2022

REVISION 2: 12/25/2024

REVISION 3: 02/06/2025

PAGE 1 OF 4

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.





ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION


HARDWARE INDENTIFICATION

Α		BACK FRAME	1PC
В		SEAT CUSHION	1PC
С	<u>••</u>	FRONT LEG	2PCS

1		LARGE BOLT (M8×75mm)	4PCS
2	<u>(</u>	SMALL BOLT (M8×65mm)	4PCS
3	<u>(</u>	SMALL BOLT (M8×55mm)	1PC
4		ALLEN KEY (M8)	1PC
5		LOCK WASHER (Φ8)	9PCS
6		FLAT WASHER (Φ8)	9PCS


ASSEMBLY INSTRUCTIONS





COASTER

ASSEMBLY INSTRUCTIONS





ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

115511 Dining Table

REVISION 0: 04/28/2022

PAGE 1 OF 4

COASTERFURNITURE.COM



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- Remove hardware from box and sort by size.
 Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION

TOP 1PC SIDE LEG 2PCS MOUNTING PLATE D **MIDDLE PANEL** 1PC 1PC


HARDWARE IDENTIFICATION

1	ALLEN WRENCH (5MM - BLK)	1PC	4	LOCK WASHER (Ø5/16" -BLK)	16PCS
2	ALLEN BOLT (Ø5/16 x 1-1/2" - BLK)	12PCS	5	FLAT WASHER (Ø5/16" x 19MM-BLK)	16PCS
3	ALLEN BOLT (Ø5/16 x 2" - BLK)	4PCS	6	PLASTIC COVER (Ø 20MM-BLK)	4PCS


ASSEMBLY INSTRUCTIONS

COASTER


STEP 1




STEP 2



STEP 3




STEP 4 COMPLETE





COASTERFURNITURE.COM





Note: Dimension tolerance ±5%