

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

115182

SIDE CHAIR

REVISION 0: 06/30/2021 REVISION 1: 07/28/2022

REVISION 2: 12/25/2024

REVISION 3: 02/06/2025

PAGE 1 OF 4

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.





ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION


HARDWARE INDENTIFICATION

LARGE BOLT


A		BACK FRAME	1PC
В		SEAT CUSHION	1PC
С	<u>••</u>	FRONT LEG	2PCS

1		(M8×75mm)	4PCS
2	(<u>)</u>	SMALL BOLT (M8×65mm)	4PCS
3	<u>()————————————————————————————————————</u>	SMALL BOLT (M8×55mm)	1PC
4		ALLEN KEY (M8)	1PC
5		LOCK WASHER (Ф8)	9PCS
6	0	FLAT WASHER (Ф8)	9PCS





COASTER FINE FURNITURE





ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

115183

ARM CHAIR

REVISION 0:06/30/2021 REVISION 1:07/28/2022 REVISION 2:12/25/2024

REVISION 3: 02/06/2025

PAGE 1 OF 4

ASSEMBLY INSTRUCTIONS



4PCS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.





ASSEMBLY TIME

10 MINUTES

PARTS IDENTIFICATION

A

SEAT AND 1PC BACK

В

BACK RIGHT 1PC LEG

c ===

BACK LEFT 1PC

D



HARDWARE INDENTIFICATION

1 () LARGE BOLT (M8×65mm)


2 (CIIIIIIIIII) SMALL BOLT (M8×60mm) 4PCS

ALLEN KEY 1PC (M8)


4 LOCK WASHER 8PCS (Φ8)

FLAT WASHER 8PCS (Φ8)





COASTER FINE FURNITURE





ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

115511 Dining Table

REVISION 0: 04/28/2022

PAGE 1 OF 4



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- Remove hardware from box and sort by size.
 Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.


- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

30 MINUTES

PARTS IDENTIFICATION




HARDWARE IDENTIFICATION

1	ALLEN WRENCH (5MM - BLK)	1PC	4	LOCK WASHER (Ø5/16" -BLK)	0	16PCS
2	ALLEN BOLT (Ø5/16 x 1-1/2" - BLK)	12PCS	5	FLAT WASHER (Ø5/16" x 19MM-BLK)		16PCS
3	ALLEN BOLT (Ø5/16 x 2" - BLK)	4PCS	6	PLASTIC COVER (Ø 20MM-BLK)		4PCS


ASSEMBLY INSTRUCTIONS

COASTER


STEP 1




STEP 2



STEP 3




STEP 4 COMPLETE





PAGE 3 OF 4





Note: Dimension tolerance ±5%