

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

115531 (B1&B2) <u>Dining Table</u>

REVISION 0: 06/21/2024 REVISION 1: 02/22/2025

PAGE 1 OF 6

COASTERFURNITURE.COM

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediatelly.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

25 MINUTES

PART IDENTIFICATION

B1 (BOX 1)

AN **TOP** 1PC 1PC CN TRESTLE BAR **LEAF** DN 2PCS

B2 (BOX 2)

BN **BASE** 2PCS

HARDWARE IDENTIFICATION

Z-B1 (BOX 1) - HARDWARE PACK IS LOCATED IN 115531 (B1)

1	THREADED BOLT (5/16" x 100mm - WHT)		2PCS
2	HALF ROUND NUT (22 x 17 x 10mm - WHT)		2PCS
3	HEX NUT (5/16" x 12 - BLK)		2PCS
4	HEX BOLT (5/16" x 50mm - BLK)		8PCS
5	LOCK WASHER (1.6 x 14mm - BLK)		8PCS
6	FLAT WASHER (1 x 18mm - BLK)	©	8PCS
7	WRENCH (M12 - RBW)		1PC
8	WOOD DOWEL (10 x 40mm - BRW)		4PCS


NOTE:


Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

ITEM: 115531(B1&B2) ASSEMBLY INSTRUCTIONS



STEP 1







ASSEMBLY INSTRUCTIONS



STEP 3







ITEM: 115531(B1&B2) ASSEMBLY INSTRUCTIONS



STEP 5







ASSEMBLY INSTRUCTIONS

COASTER

STEP 7




STEP 8 COMPLETE



PAGE 6 OF 6

COASTERFURNITURE.COM





Note: Dimension tolerance ±5%



ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

115562 Side Chair

REVISION 0: 06/21/2024

PAGE 1 OF 4

ITEM: 115562

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instruction in the same sequence as numbered to assure fast and easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishment.





15 MINUTES


PARTS IDENTIFICATION


SEAT AND BACK 1PC Α В **FRONT LEG** 2PCS C **BACK LEG** 2PCS HARDWARE IDENTIFICATION **LONG BOLT** 4PCS 1 (M8 x 60mm - BLK) 2 **SHORT BOLT** 4PCS (M8 x 50mm - BLK) **LOCK WASHER** 8PCS 3 (M8 - BLK) 8PCS **FLAT WASHER** (M8 - BLK) **ALLEN WRENCH** 1PC 5 (M5 - BLK)

ITEM: 115562 ASSEMBLY INSTRUCTIONS

COASTER

STEP 1







ITEM: 115562
ASSEMBLY INSTRUCTIONS



STEP 3 COMPLETE







Note : Dimension tolerance ± 5%